



## Program overview

Program	Temperature	Speed	Load
<b>Normal</b> Cotton, linen, and mixed-fiber fabrics made of both cotton and linen.	Hot +, Hot, <b>Warm +</b> , Warm, Cold	Max.	<b>Full load</b> (17.6 lb/8 kg)
<b>Delicates</b> For delicate fabrics made from synthetic fibers.	Hot +, Hot, <b>Warm +</b> , Warm, Cold	Med. Slow,	<b>Small load</b> (6.6 lb/3 kg)
<b>Sanitize</b> Cotton or linen fabrics with direct skin contact or for which special hygiene requirements apply.	<b>Sanitize</b>	Max. High,	<b>Full load</b> (17.6 lb/8 kg)
<b>Handwash</b> For delicate fabrics which are only suitable for hand washing.	Hot, <b>Warm +</b> , Cold	High, Med, Slow,	<b>Small load</b> (4.4 lb/2 kg)
<b>Dress Shirts</b> Pre-treat collars and cuffs depending on the level of soiling.	Hot +, Hot, <b>Warm +</b> , Warm, Cold	Med. Slow,	<b>Small load</b> (4.4 lb/2 kg)
<b>Darks/Denims</b> Black and dark garments made from cotton, mixed fibers, and denim.	<b>Warm +</b> , Warm, Cold	High, Med, Slow,	<b>Small load</b> (4.4 lb/2 kg)
<b>MobileStart</b> The Miele app is used to select programs and operate the appliance.			
<b>Express</b> Cotton linens and drapes made of cotton and linen.	Warm +, <b>Warm</b> , Cold	High, Med, Slow,	<b>Half load</b> (7.7 lb/3.5 kg)
<b>Extra White</b> For white fabrics made of cotton or linen without special hygiene requirements.	Hot +, Hot, <b>Warm +</b> , Warm, Cold	Max. High,	<b>Full load</b> (17.6 lb/8 kg)
<b>Outdoor</b> Performance outerwear (e.g., jackets and pants) made from membrane fabric such as Gore-Tex®, SYMPATEX®, WINDSTOPPER®, etc.	<b>Warm +</b> , Warm, Cold	Med, Slow,	<b>Small load</b> (5.5 lb/2.5 kg)
<b>Proofing</b> Treating microfiber fabric, ski wear, or table linens/drapes made from mainly synthetic fibers to provide a finish which is resistant to water and dirt.	High, Med, Slow,	Med, Slow,	<b>Small load</b> (5.5 lb/2.5 kg)
<b>Table Linens/Drapes</b> Table linens and drapes made of cotton and linen.	Hot +, Hot, <b>Warm +</b> , Warm, Cold	High, Med, Slow,	<b>Full load</b> (13.2 lb/6 kg)
<b>Sportswear</b> Sportswear such as jerseys and leggings, as well as microfiber and fleece garments.	Hot +, Hot, <b>Warm +</b> , Warm, Cold	High, Med, Slow,	<b>Half load</b> (6.6 lb/3 kg)
<b>Woolens </b> Wool or wool-blend fabrics.	<b>Warm</b> , Cold	High, Med, Slow,	<b>Small load</b> (4.4 lb/2 kg)
<b>Silks </b> Silks and other hand-washable fabrics with no wool content. Place tights, bras, etc., in a laundry bag.	<b>Warm</b> , Cold	Slow,	<b>Very small load</b> (2.2 lb/1 kg)
<b>Wrinkle-free</b> Synthetic or mixed-fiber fabrics, or wrinkle-free cotton.	Hot +, Hot, <b>Warm +</b> , Warm, Cold	High, Med, Slow,	<b>Half load</b> (8.8 lb/4 kg)
<b>Baby Clothes</b> Baby clothes, baby towels, bath gowns, toweling items, bibs made from cotton.	Hot +, Hot, <b>Warm +</b> , Warm, Cold	Max. High, Med, Slow,	<b>Full load</b> (13.2 lb/6 kg)
<b>Towels</b> For linen or cotton towels used for personal hygiene.	Hot +, Hot, <b>Warm +</b> , Warm, Cold	Max. High, Med, Slow,	<b>Full load</b> (11 lb/5 kg)
<b>Downs</b> Jackets, sleeping bags, pillows, and other down-filled items.	Hot +, Hot, <b>Warm +</b> , Warm, Cold	High, Med, Slow,	<b>Small load</b> (4.4 lb/2 kg)
<b>Pillows</b> Washable pillows with synthetic filling.	Hot +, Hot, <b>Warm +</b> , Warm, Cold	High, Med, Slow,	<b>2 pillows</b> (40 x 80 cm) or <b>1 pillow</b> (60 x 80 cm)
<b>Clean Machine</b> With frequent washing at low temperatures there is a danger of a build-up of bacteria in the washing machine. Cleaning the washing machine will significantly reduce bacteria and prevent the build-up of unpleasant odors.	<b>Sanitize</b>	Slow	<b>Without load</b>

## Detergent

	Miele UltraPhase 1 and 2		Miele Capsules		
Normal	✓	-	✓	✓	✓
Delicates	✓	✓	✓	✓	-
Sanitize	✓	-	✓	✓	✓
Handwash	-	✓	✓	✓	-
Dress Shirts	✓	-	✓	✓	✓
Darks/Denims	✓	-	✓	✓	-
Express	✓	-	✓	✓	-
Extra White	✓	-	✓	✓	✓
Outdoor	-	✓	-	-	-
Proofing	-	-	✓	-	-
Table Linens/Drapes	✓	-	✓	✓	✓
Sportswear	-	✓	-	-	-
Woolens	-	✓	-	-	-
Silks	-	✓	-	-	-
Wrinkle-free	✓	-	✓	✓	✓
Quick Rinse	-	-	✓	-	-
Baby Clothes	✓	-	✓	✓	✓
Towels	✓	-	✓	✓	✓
Downs	-	✓	-	-	-
Pillows	✓	-	-	-	-

✓ Recommendation  
 - No recommendation


Special-purpose detergents (e.g., WoolCare)  
 Fabric care (e.g., fabric softener)  
 Additives (e.g., booster)

## Cleaning and care

### Cleaning the detergent drawer

Washing at low temperatures and the use of liquid detergent can lead to a build-up of bacteria in the detergent drawer.


- Clean the entire drawer at regular intervals for hygiene reasons, even if you are using the TwinDos system exclusively.



- Press down the release button and, at the same time, pull the drawer completely out of the machine.


### Removing and cleaning the insert for liquid detergents

An insert for liquid detergents is located in the compartment of the detergent drawer.



### Cleaning the siphon inside the compartment

Compartment 1 has a siphon for better dispensing of the chlorine bleach.



- Remove the release catch.

### Cleaning the siphon inside the compartment

Remove the siphon and clean under warm running water.



- Remove the siphon from the compartment and clean under warm running water.



- Use a bottle brush to remove detergent residues and limescale from the jets inside the detergent-drawer housing.

### Sanitize info (cleaning the drum)

Washing at low temperatures and/or using liquid detergents can cause bacteria and odors to build up in the washing machine. Use the *Clean Machine* program to clean the washing machine. Note the message in the display: Sanitize info: Run a high temp. program or the "Clean Machine" program



- Replace the detergent drawer.

**Tip:** Leave the detergent drawer slightly open to allow it to dry.

## Frequently asked questions ...

Problem	Possible cause and solution
<b>The control field remains dark.</b>	<ul style="list-style-type: none"> <li>There is no power to the machine.               <ul style="list-style-type: none"> <li>■ Check whether the plug is plugged in.</li> <li>■ Check whether the fuse has tripped.</li> </ul> </li> <li>The washing machine has switched off automatically to save energy.               <ul style="list-style-type: none"> <li>■ Switch the washing machine on again by turning the program selector.</li> </ul> </li> </ul>
<b>The following appears in the display:</b> 	<ul style="list-style-type: none"> <li>The door is not closed properly. The door lock could not engage.               <ul style="list-style-type: none"> <li>■ Close the door again.</li> <li>■ Start the program again.</li> </ul> </li> <li>If the fault message appears again, contact Miele Customer Service.</li> </ul>
Drainage See	<ul style="list-style-type: none"> <li>The drain is blocked or restricted. The drain hose has been fixed too high.               <ul style="list-style-type: none"> <li>■ Clean the drain filter and the drain pump.</li> <li>■ The maximum drain height is 39 3/8" (1 m).</li> </ul> </li> </ul>
Water intake See	<ul style="list-style-type: none"> <li>The water intake is blocked or restricted.               <ul style="list-style-type: none"> <li>■ Check whether the faucet is turned on properly.</li> <li>■ Check whether the intake hose is kinked.</li> <li>■ Check whether there is sufficient water pressure.</li> </ul> </li> </ul>
Waterproof system Turn off  Service	<ul style="list-style-type: none"> <li>The filter in the water intake is blocked.               <ul style="list-style-type: none"> <li>■ Clean the filter.</li> </ul> </li> <li>The water protection system has reacted.               <ul style="list-style-type: none"> <li>■ Close the faucet.</li> <li>■ Contact Customer Service.</li> </ul> </li> </ul>
Service Fault F	<ul style="list-style-type: none"> <li>There is a fault.               <ul style="list-style-type: none"> <li>■ Disconnect the washing machine from the power supply. Unplug the appliance or switch off the breaker.</li> <li>■ Wait <b>at least 2 minutes</b> before reconnecting the washing machine to the power supply.</li> <li>■ Switch the washing machine on again.</li> <li>■ Restart the program.</li> </ul> </li> <li>If the fault message appears again, contact Miele Customer Service.</li> </ul>

Problem	Possible cause and solution
Check dosage	<ul style="list-style-type: none"> <li>Excessive foam has built up during washing.               <ul style="list-style-type: none"> <li>■ With TwinDos, check the dosage amount set.</li> <li>■ Reduce the amount set in 10% increments.</li> <li>■ Use less detergent next time and follow the manufacturer's instructions on dosage given on the packaging.</li> </ul> </li> </ul>
Sanitize info: Run a high temp. program or the "Clean Machine" program	<ul style="list-style-type: none"> <li>When washing, a wash program using a temperature above 60°C (140°F) has not been run for a long time.               <ul style="list-style-type: none"> <li>■ Turn the program selector to the <i>Additional programs</i>  setting and select the <i>Clean Machine</i> program in the Care submenu.</li> <li>■ Run the <i>Clean Machine</i> program using the Miele Machine Cleaner or a universal powder detergent.</li> </ul> </li> <li>The washing machine is cleaned which prevents bacteria and odor buildup.</li> </ul>
Align the washing machine	<ul style="list-style-type: none"> <li>The <i>SoftSteam</i> extra option which runs at the end of the program could not be carried out properly.               <ul style="list-style-type: none"> <li>■ Check whether the washing machine is aligned correctly (see "Installation – Leveling the machine").</li> <li>■ Check whether the maximum drain height of 39 3/8" (1 m) has been exceeded.</li> </ul> </li> <li>If the fault message appears again, contact Miele Customer Service. The washing machine can still be used, but without the <i>SoftSteam</i> extra option.</li> </ul>
is almost empty. Only a few more cycles are possible	<ul style="list-style-type: none"> <li>The detergent in the cartridge is running low. There is enough left for approx. 4 to 8 wash programs.               <ul style="list-style-type: none"> <li>■ Order a new cartridge.</li> </ul> </li> <li>The door lock has jammed.               <ul style="list-style-type: none"> <li>■ Contact Customer Service.</li> </ul> </li> </ul>
<b>The following appears in the display:</b> 	<ul style="list-style-type: none"> <li>There is a fault.               <ul style="list-style-type: none"> <li>■ Disconnect the washing machine from the power supply. Unplug the appliance or switch off the breaker.</li> <li>■ Wait <b>at least 2 minutes</b> before reconnecting the washing machine to the power supply.</li> <li>■ Switch the washing machine on again.</li> <li>■ Restart the program.</li> </ul> </li> <li>If the fault message appears again, contact Miele Customer Service.</li> </ul>

## Miele

### Quick Start Guide

### Washing machine



This Quick Start Guide is not a substitute for the operating instructions supplied with the appliance! It is essential to familiarize yourself with the washing machine before using it for the first time. Please read the operating instructions carefully and pay particular attention to the IMPORTANT SAFETY INSTRUCTIONS.