




30" ELECTRIC FREESTANDING STANDARD CLEAN RANGE

MODELS:

WFE515S0JS0 (Stainless)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	5	W10275048	Element (3000/1400W)	9	7101P485-60	Screw, Anti-Tip Kit
	W11333088	Instructions, Installation			(Left Front)			FOLLOWING PARTS NOT ILLUSTRATED
	W11333073	Use and Care Guide		W10248261	Element (1200W)	W11171889		Harness, Wire (Main)
	W11351201	Sheet, Tech			(Left Rear, Right Rear)	W11134551		Harness, Cooktop (Right)
	W11351205	Diagram, Wiring		8273992	Element (2500W)	W11134603		Harness, Cooktop (Left)
2	W10225448	Spring, Element			(Right Front)			
3	W10607641	Bracket, Cooktop (Left)	6	3196169	Screw			
	W10607642	Bracket, Cooktop (Right)	7	W10691223	Pan, Radiant Element			
4		Cooktop	8	W10306542	Bracket, Anti-Tip			
	W11034830	Black						


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap	4	W10434452	Switch, Infinite (Dual)	6		Control, Electronic (LCX)
	W11130372	Black (Left)			(Left Front)		W11204514	Black
	W11130379	Black (Right)		3148951	Switch, Infinite	7	W10525121	Bracket, Console Mounting
2	W10695491	Bracket, Control			(Right Rear and Left Rear)			
3		Console, Assembly		3148954	Switch, Infinite (Orange)	8	W10134247	Shield, Heat
	W11027387	Stainless			(Right Front)	9	3400882	Screw
			5		Knob	10	8272473	Cover, Upper Rear
				W11022718	Black	11	3196178	Screw


CHASSIS PARTS



CHASSIS PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10289077	Receiver, Hinge	16	W10058460	Foot, Leveling	34	W10627802	Switch, Door
2	3196154	Screw	17	3196548	Fuse, Thermal	35	W10281322	Kit, Bare Wire Adapter Block
3		Panel, Side	18	3196172	Screw	36	W11092984	Screen, Vent
	W10162245	Black	19	W10404688	Clip, Oven Support	37	9761013	Assembly, Door Latch (Front)
4	3400029	Nut	20	3186034	Bracket, Service	38	3196560	Screw
5	W10658354	Seal, Door	21	W10245259	Block, Terminal	39	W10078380	Rod, Latch
6	9757340	Element, Broil	22	W10910404	Counterweight	40	W10107820	Assembly, Door Latch (Rear)
7	W11111743	Element, Bake	23	3196178	Screw			FOLLOWING PARTS NOT ILLUSTRATED
8	3196174	Screw	24	W11175594	Assembly, Light			
9	W10134285	Tube, Vent	25	W10571723	Bulb, Halogen 40 Watts			
10	W10674705	Glide, Drawer Front	26	3400016	Screw		W10774939	Insulation, Wrap
11	W10341186	Assembly, Front Foot	27	W10181986	Sensor, Oven		W11127325	Insulation, Back
12	W10067840	Screw	28	3196169	Screw		W10333344	Insulation, Flue
13	8054068	Retainer, Insulation	29	W10326122	Cover, Terminal Block			
14	W10137382	Clip, Panel	30	W10031780	Screw			
15	W10390008	Assembly, Base Rail (Left)	31	9757239	Rod, Door Switch			
	W10390007	Assembly, Base Rail (Right)	32	W10268578	Rack, Oven			
			33	W11034869	Screw			

DOOR PARTS




DOOR PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Trim, Top (Includes Standoff)
	W11241393	Stainless
2	W10480830	Screw
3		Handle, Door
	W11249084	Stainless
4	9761344	Liner, Door
5	W10031790	Screw
6	9758162	Glass, Inner

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
7	9761357	Retainer, Insulation
8	W10299224	Hinge, Active (With Spring)
9	W10278991	Insulation, Door Strip
10		Trim, Side
	W10746436	Black (Left)
	W10746435	Black (Right)
11	W10327235	Screw
12	W10884775	Nameplate

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
13	W10031780	Screw
14	W10544179	Strap, Door
15	W10200660	Screw
16		Glass, Outer Door
	W10884159	Black
17	W10316950	Frame, Glass
18	W10299227	Hinge, Door (Passive)
19		Trim, Lower Door
	8523177	Black

DRAWER PARTS



DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Panel, Drawer Front	2	W10688022	Drawer, Storage	4	W10674708	Glide, Drawer Rear
	W10330070	Stainless	3	W10462910	Bracket, Mounting Drawer	5	3196165	Screw

OPTIONAL PARTS

REFINISHING MATERIAL

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	511873	White Porcelain (2 oz.)

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

INSULATION

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2" x 24" x 120")
	240132	Insulation (2-1/2" x 22" x 120")

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black
	206922	Primer (White)

ACCESSORY PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	4396923	Grid, Broiler Pan and
	W10355016	Cleaner, Stainless Steel
	W10355051	Cleaner, Cooktop
	WA906B	Scraper, Cooktop
	4396096RB	Griddle
	4396923	Grid, Broiler Pan and
	W10123240	Rack, Broiler Pan & Roasting