

Read this **before** installing the hood: The following installation instructions assume that there is a solid surface behind the wall as outlined in the Operating and Installation instructions! Wall anchors included in the packaging are not for use in USA / CDN.
CAUTION: During the installation process, please be careful of sharp edges that can cause harm.

Lire ces renseignements avant d'installer la hotte: Les instructions pour l'installation suivantes exigent qu'il y ait une surface solide derrière le mur, tel qu'indiqué dans les Instructions pour l'utilisation et l'installation! Les ancrages muraux compris dans l'emballage ne sont pas destinés aux É.-U. / Canada.

MISE EN GARDE: Durant l'installation, veuillez faire attention aux rebords tranchants qui pourraient vous blesser.

AE
 Air extraction mode -
 Mode d'évacuation

RM
 Recirculation mode -
 Mode de circulation d'air

1

2

3

4

5

6

7

8 AE

8 RM

9

10

11

12

13 RM

13 AE

14

15

16 RM

17

18

19

20

21

22 RM

23