EQK

Portable Air Conditioner

User's Manual

Model: EAP01

EQK

70 years of kool living

Emerson Quiet Kool Co. Ltd.
1271 Bloomfield Ave, 19-235 Fairfield,
NJ 07004, USA
Toll Free Number: 1-844-801-8880

Toll Free:1-844-801-8880
EMERSON reserves the rights to make changes without further notice to improve its reliable products work. Check with your local authority or retailer for recycling advice.

Table of contents

Warnings	3
Identification Of Parts	5
Control Panel	9
Functional Operation	10
Care And Cleaning	11

Specification

Specifications

Please meet in the camera pic for reference only; variation may result due to the application countries or regions, and shall be based on practical operation.

Model No.	EAP01
Input Power	240W
Cooling Capacity	10000TU
Cooling Current	10A
Rated Voltage	DC 24V
Air Flow Volume	480CFM
Noise Level	≤50dB(A)
Discharge Side Pressure	2.8MPa
Suction Side pressure	0.6MPa
Refrigerant	R134A,50g
Maximum Pressure	4.2Mpa
Electrical Protection	Class 1
Net Weight	7.8kg

Electric waste products should not be disposed of with household waste. Please dispose of this product responsibly. Check with your local authority or retailer for recycling advice.

Warnings

Precautions For Use

Please read "Precautions" carefully before operating your machine The following signs and symbols in "Precautions" must be observed for safe operation.

Warning	Means improper handling may result in a death or a serious injury to a person.
Caution	Means improper handling may result in an injury or damage to properties.
Shows	Prohibition
Shows	Compulsion
Shows	Caution

Warnings

- In case of any abnormality, turn off this machine immediately and, disconnect the plug and contact to the seller of your appliance.
  (Abnormal operation may result in a failure of the unit, electric shock, fire, or the like.)
- DO NOT attempt to turn off this machine by disconnecting the plug.
- DO NOT disassemble or repair this unit by yourself.
- To avoid accidents caused by electric shock, please keep your hands dry when plugging or unplugging.
- Clean any dust from the blades of the power plug and insert the plug into an outlet.

Prevent water ingress

Keep off dust

- To avoid fire or other accidents, do not spray this machine with water, and do not place flammable or chemical substances near this unit.
- To prevent resin parts from melting or catching on fire, do not place this machine near portable heaters.
- DO NOT connect this machine to an outlet having the electrical ratings below the product's requirements.
- The power cord must not be damaged or modified. Do not place anything hot or heavy on the cord. Do not pull the cord out , or bundle it during operation.
- To avoid damages to the power cord, avoid pinching the cord in a door.
- Never place any objects into the openings of this machine. This unit contains moving parts. Operating at high speed, contact with the moving fan can cause serious injury.
- Remove water that has been collected in the tank. (Accidentally dirtying of the water or using it for other purpose may cause illness and /or unforeseen accidents.)
- To avoid electric shock disconnect power before servicing unit Moving parts do not operate unless unit back cover removed. Inst parts. Do not operate unit with back cover removed.
  (In case of any water spills, into the unit can deteriorate the insulation.)

Correct Disposal of this product

This marking indicates that this product should not be disposed with other household wastes throughout the EU.To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

Warnings

- As ⚠ "The appliance shall be installed in accordance with national wiring regulations"
- "If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard."
- "This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved."
- "Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children."

Cautions

- This machine must be used on a level and stable surface.
- To prevent the water from freezing, do not use this machine and the drain hose at ambient temperature below 41 °F.
- Do not use this machine outside. Exposure to direct sunlight or rain may result in malfunction, deterioration of the machine.
- Do not put water container on this machine.
- Do not use the unit in places subject to chemicals.
- Do not use this machine where any leakage of oil or flammable gas may take place.
- Be careful not to place an electric heater near the fan of this product.
- Do not to sit or step on this unit.

Keep off dust

Prohibit

Prohibit

Prohibit

Prohibit

Prohibit

Prohibit

Condition

Identification Of Parts

Identification Of Parts

1. Operation Panel
2. USB
3. Air Vent
4. Flashlight
5. Exhaust Duct Pipe
6. Continuous Drain
7. Foot Pad
8. Filter

Open the package, take out the machine, and let the machine stand for 24 hours before first use. Assemble the attached parts of the machine as shown below.

Accessories Include

1. Exhaust duct pipe.
2. Continuous drain.
3. User manual.

1. Screw the exhaust pipe to the rear air outlet (as shown)

Control Panel

Control Panel

Key Description

①	Power switch ——Press this button to turn the machine on and off.
②	Bluetooth function switch——Press this button to turn the Bluetooth function on and off.
③	Volume down——Press this button to decrease the volume of the Bluetooth speaker.
④	Volume up——Press this button to increase the volume of the Bluetooth speaker.
⑤	Fan speed setting——Press this button to set the high or low wind speed switch in the cooling and fan only mode of the machine.
⑥	Cooling mode setting——Press this button to set the running cooling mode
⑦	Fan only mode setting——Press this button to set the fan only mode.
⑧	Flashlight——Press this button to run the illumination, switch between high and half and half light.

Tip: The compressor has a 3-minute protection function, and it takes 3 minutes to restart after stopping.

Cooling mode

1. In the power on state, press the cooling button to run the cooling mode, and the corresponding indicator light displays a blue light.
2. In the cooling mode, you can press the fan speed setting button to control the temperature. When the ambient temperature ≥ 29°F running cooling mode, 41°F is when the ambient temperature ≤ 59°F running fan only mode, the machine will automatically stop cooling.
3. In the cooling mode, you can press the fan speed setting button to control the wind speed.

Tip: When voting, try to reduce the length of the duct, keep away from the direct sunlight, and try to keep the indoor closed, and the cooling effect is better.

Ventilation mode

1. In the power on state, press the fan only mode setting button to open to the fan only mode, and the corresponding indicator light displays a red light.
2. In the fan only mode, you can press the fan speed setting button to control the wind speed.

Lighting function:

1. Press the illumination button for the light to be fully illuminated (corresponding indicator light is red).
2. In the full light mode, press the illumination button again and the light is half illuminated (corresponding indicator light is green).
3. In the half light mode, press the illumination button again to turn off the light.

Bluetooth function:

1. Press the Bluetooth function button and the Bluetooth function will be enabled.
2. Then, you can turn on the Bluetooth function of the mobile device and connect the Bluetooth speaker of the machine.
3. When the machine makes a beep, it indicates a successful connection, and then you can play music.

Water full reminder:

When the humidity is greater than 70% or the temperature is greater than 29°F, the water full light will flash, and the cooling function will stop. Water full light flashes red. Please remove the water plug to drain the machine. When draining, pay attention to the water inside the machine.

Charging function:

Output: 5V, 2A is only used to charge mobile phones or tablets, not to transfer music as 3.5W.

Care And Cleaning

Care And Cleaning

Every two weeks of usage, Clean the fan.

- Cut off the power supply to ensure that the machine is off.
- Take out the filter.
- Use a soft brush to clean the brush.
  Note: Failure to keep air filter clean will result in poor air circulation. DO NOT clean the screen while it's on the machine, you need to remove the screen (st.

Tip: to reduce the risk of fire, electric shock or injury while using air conditioner, the following basic precautions should be followed:

1.The socket must be a 3-pronged socket plugged with a ground pin.
2.Don't drag on the ground.
3.Don't use extension cords.
4. Unplug the air conditioner before performing normal maintenance.

5.This appliance should not be used by children under the aged age of 8 years or by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of this appliance in a safe way and fully understand the hazards involved. Children SHOULD NOT play with the appliance. Cleaning and user maintenance shall not be made by children.

6. Correct Disposal of this product
This marking indicates that this product should not be disposed with other household wastes. To prevent possible harm to the environment or personal health from waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.