

## WASH CYCLE FEATURES




### Auto Wash

- The dishwasher can measure how dirty the dishes are to adjust water consumption and temperature accordingly.




### Pots + Pans

- The ability to dissolve grease on heavily soiled dishes, like pans, casseroles and oven dishes.



### Normal Wash

- Recommended for daily, regular, or typical use to completely wash a full load of normally soiled dishes.




### Quick Wash

- This program is used for glasses and porcelain that is lightly soiled, such as coffee cups.
- Combined with Speed Wash, a shorter program is achieved in 15 minutes.




### Rinse + Hold

- Used to rinse dishes between full wash cycles.



### Quick Intensive

- Auto Wash + Speed Wash + Auto Open
- Effective for dishes with slightly dried leftovers.



### Self Clean

- This cycle sanitizes the dishwasher tub, spray arms, and spray pipes.