


CF70B0W Exploded View



CF70B0W Parts list

| No. | Parts code | Description of Spare Part | Quantity |
|-----|--------------|-------------------------------|----------|
| 1 | 20201020020 | Door | 1 |
| 2 | 3020400250 | Door gasket | 1 |
| 3 | 501105040009 | Ice Scraper | 1 |
| 4 | 3039900254 | Food box | 1 |
| 5 | 20122990648 | Drain-pipe plug | 1 |
| 7 | 20106990029 | Cover of compressor | 1 |
| 8.1 | 3050500011 | Indicator light | 1 |
| 8.2 | 3050500019 | Indicator light | 1 |
| 9 | 20122010167 | Thermostat knob | 1 |
| 10 | 2208100031 | Thermostat display card | 1 |
| 11 | 2400200002 | Thermostat | 1 |
| 12 | 20060745 | Drier filter | 1 |
| 13 | 20060046 | Connecting tube | 1 |
| 14 | 20122990649 | Drain-pipe decorative cover | 1 |
| 15 | 20061718 | Process tube | 1 |
| 16 | 3040100307 | compressor | 1 |
| 17 | 20105050013 | Compressor base support | 1 |
| 18 | 2500100002 | Power supply cord plug | 1 |
| 19 | 3050200284 | Connecting wire of compressor | 1 |
| 20 | 20122990708 | Scroll wheel | 2 |
| 21 | 3031400173 | Door hinge assembly | 1 |
| 22 | 3039900311 | Cover of door hinge | 2 |
| 23 | 3039900310 | Cover of door hinge | 2 |
| 24 | 3031400174 | Door hinge assembly | 1 |