

WIRING DIAGRAM

SCHEMATIC
NOTE: CONDITION OF OVEN
1. DOOR CLOSED.
2. CLOCK APPEARS ON DISPLAY.

SCHEMATIC DIAGRAM (DOOR CLOSED, COOK OFF CONDITION)




Figure O-1. Oven Schematic-Off Condition

SCHEMATIC
NOTE: CONDITION OF OVEN
1. DOOR CLOSED.
2. COOKING TIME PROGRAMMED.
3. "START" PAD TOUCHED.




Figure O-2. Oven Schematic-Microwave Cooking Condition