


MICROWAVE DRAWER TECH SHEET

Schematic Diagram

Warning : Power must be disconnected before servicing this appliance

MODEL NO. : UMBW2411AS/UMBW3011AS



[CONDITION]
DOOR : CLOSED
COOK : OFF

NOTE :

DL : OVEN LAMP
FM : FAN MOTOR
SM : STIRRER PAN MOTOR
DM : DRAWER DC MOTOR

BK : BLACK BL : BLUE
RD : RED BR : BROWN
WH : WHITE GN : GREEN
YW : YELLOW

Wiring Diagram

Warning : Power must be disconnected before servicing this appliance

MODEL NO. : UMBW2411AS/UMBW3011AS

