


## MIXER

### MODELS:


KHM512AQ0 (Aqua Sky)  
KHM512BM0 (Black Matte)  
KHM512BY0 (Boysenberry)  
KHM512CB0 (Cranberry)  
KHM512CL0 (Crystal Blue)  
KHM512CU0 (Contour Silver)  
KHM512ER0 (Empire Red)  
KHM512FG0 (Matte Gray)  
KHM512GA0 (Green Apple)  
KHM512GT0 (Garnet)  
KHM512GU0 (Guava Glaze)  
KHM512HT0 (Hot Sauce)  
KHM512IB0 (Ink Blue)  
KHM512IC0 (Ice Blue)  
KHM512LR0 (Lavender Cream)  
KHM512MF0 (Matte Fog Blue)

KHM512MY0 (Majestic Yellow)  
KHM512OB0 (Onyx Black)  
KHM512PH0 (Bird of Paradise)  
KHM512PI0 (Pistachio Matte)  
KHM512PK0 (Pink)  
KHM512PT0 (Pistachio)  
KHM512TB0 (Twilight Blue)  
KHM512TG0 (Tangerine)  
KHM512VB0 (Blue Velvet)  
KHM512WH0 (White)  
KHM512WM0 (Watermelon)  
KHM512TCB0 (Cranberry/Flamingo)  
KHM512TER0 (Empire Red)  
KHM512TWH0 (White)  
4KHM512TCB0 (Cranberry/Flamingo)



# UNIT PARTS



3



Literature Parts



# UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	2	W10423810	Knob, Speed Control
	W11483223	Use and Care Guide	3	W10490648	Beaters (includes Right and Left)