

KitchenAid®

SIFTER AND SCALE ATTACHMENT


MODELS:

KSMSFTA0 (United States)

5KSMSFTA0 (Europe)

5KSMSFTAA0 (Australia)

SIFTER AND SCALE ATTACHMENT PARTS



SIFTER AND SCALE ATTACHMENT PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	3	W11281846	Hopper Assembly	5	W11281853	Housing, Sift Assembly
	W11221344	Use & Care Guide (United States)	4	W11281849	Scale Assembly (United States)	6	W11281854	Chute Assembly
	W11221346	Use & Care Guide (Europe)		W11286824	Scale Assembly (Europe)	7	W11281859	Sifter Assembly
	W11221354	Use & Care Guide (Australia)		W11286836	Scale Assembly (Australia)	8	W11281865	Screen
2	W11281848	Weight Plate						