

# Convection, broiler, toaster and microwave oven in one.



**Convection  
Cooking**

## Convection, broiler, toaster and microwave in one

Everything you need in one powerful appliance: convection oven for even cooking, toaster oven, broiler, microwave oven and range hood.



**Ceramic  
Enamel  
Interior**

## Scratch resistant and easy to clean

With Ceramic Enamel inside, it's easy to keep your microwave spotless. Now you can effortlessly remove grease or oil from surfaces.



**LED  
Cooktop  
Light**

## Illuminates your cooktop

The industry's only LED cooktop light\* – bright, soft and energy efficient.

*\*As of March 15, 2012.*

Available Colors:

Stainless

**SAMSUNG**



## Convection Cooking

### Convection, broiler, toaster and microwave in one

**Enjoy the flexibility** to microwave, bake, broil and roast – all from one appliance

**Combination of convection cooking** and microwave heating cooks faster and more evenly than traditional microwave\*

*\*Fresh vegetables in less than two minutes. Roasted chicken in 14 minutes. Two potatoes will bake in 11 minutes.*



## Ceramic Enamel Interior

### Scratch resistant and easy to clean

**More scratch and stain resistant** than plastic or stainless steel



## LED Cooktop Light


### Illuminates your cooktop

**LED lights** are significantly brighter than halogen or incandescent bulbs and save more energy\*

**Evenly distributes** a soft, bright light across your cooktop

*\*Power consumption for Samsung standard OTR incandescent bulb is 40 W as compared to LED, which is 2.4 W (energy savings).*





### EZ Filter™ Change

## Easy reach, easy clean

**Convenient, easy-to-access location** is simple to eject and helps you remember when to clean the filter

**Change the filter** every month to maintain microwave performance



### Steam Cleaning

## An easier, more natural way to clean

**Steam cleans** the microwave for you; save time and money on cleaning supplies

**Pour 3 ounces of water** in a bowl, place inside, press Steam Clean and wipe clean after seven minutes



### Eco Mode Button

## Conserves power intelligently with the push of a button

**Conserves power** by turning off display when not in use

**More convenient** than unplugging the microwave when not in use

