


Model no: OB30DDEPX3 (refer page 2 for metric measurements)

	Product	Dimensions	in
	Overa	all height* of oven	48 1/2'
	Over	all width of oven	29 29/32'
	© Dept dials)	h of oven front and control panel** (excludes handle and	1 17/32'
	Dept	h of oven chassis (does not include oven front)	22 13/32'
	E Heigh	nt from bottom datum to top of stainless fascia cap	45 9/16'
	F Heigh	nt from bottom datum to bottom of stainless fascia cap	43 25/32'
	© Heigh	nt from bottom datum to top of top door	43 5/16'
	Heigh	nt from bottom datum to top of top stainless door cap	26 1/16'
	I Height	nt from bottom datum to bottom of top stainless door cap	22 17/32'
	J Heigh	nt from bottom datum to top of bottom door	21 15/16'
OF CARCASS	K Heigh	nt from bottom datum to top of bottom stainless door cap	4 11/16'
	L Heigh	nt from bottom datum to top of vent	1 5/32
	Meigh	nt from bottom datum to top of top handle	42 9/32
	N Heigh	nt from bottom datum to bottom of top handle	41 21/32
-	O Height	nt from bottom datum to top of bottom handle	20 29/32
Ο	Height	nt from bottom datum to bottom of bottom handle	20 9/32
	④ Heigh	nt of chassis	47 15/16
		h of door (open) (measured from front of door)	20 7/8
0	© Overa	all width of chassis	28 11/32'
	① Widt	h of handle	28 5/8
	U Dept	h of handle (measured from front of door)	1 21/32
		ght measurements included mounted feet irred to front glass surface and excludes 3/32" stainless cap	
	Minimur	n Clearances	ir
	Minimun	n inside height of cavity from bottom datum	48 3/16'
		n inside width of cavity	28 1/2'
	O Minimun	n inside depth of cavity from front datum	22 5/8'

DATE: 11.06.2015

IMPORTANT NOTE: Throughout this guide, dimensions may vary by $\pm 2mm$ (3/32"). Please read the installation manual for detailed information on installing the product. www.fisherpaykel.com

Fisher&Paykel _____



Inches

760mm Double Pyrolytic Built-in Oven

Model no: **OB30DDEPX3** (refer page 1 for imperial measurements)

	Product Dimensions	mm
	Overall height* of oven	1232
	Overall width of oven	760
	© Depth of oven front and control panel** (excludes handle and dials)	39
	Depth of oven chassis (does not include oven front)	569
	E Height from bottom datum to top of stainless fascia cap	1157
	F Height from bottom datum to bottom of stainless fascia cap	1112
	G Height from bottom datum to top of top door	1100
	(H) Height from bottom datum to top of top stainless door cap	662
	I Height from bottom datum to bottom of top stainless door cap	572
	 Height from bottom datum to top of bottom door 	557
	© Height from bottom datum to top of bottom stainless door cap	119
	© Height from bottom datum to top of vent	29
	Height from bottom datum to top of top handle	1074
	N Height from bottom datum to bottom of top handle	1058
	Height from bottom datum to top of bottom handle A statement of the statement o	531
-1	P Height from bottom datum to bottom of bottom handle	515
	 Height of chassis 	1218
<u>}</u>	® Depth of door (open) (measured from front of door)	530
	© Overall width of chassis	720
	① Width of handle	727
	 Depth of handle (measured from front of door) 	42
	* All height measurements included mounted feet ** Measured to front glass surface and excludes 2mm stainless cap	
	Minimum Clearances	mm
	Minimum inside height of cavity from bottom datum	1224
	Minimum inside width of cavity	724
Θ	Minimum inside depth of cavity from front datum	575

INDICATES CABINETRY CARCASS DATUM INDICATES MINIMUM CABINETRY CLEARANCES

DATE: 11.06.2015

IMPORTANT NOTE: Throughout this guide, dimensions may vary by ±2mm (3/32"). Please read the installation manual for detailed information on installing the product. www.fisherpaykel.com

Fisher&Paykel _____

