
# DATA SHEET



## 790MM ACTIVESMART™ FRIDGE - FRENCH DOOR

RF170ADX4, RF170ADX5

(refer page 2 for metric measurements)

Product Dimensions	in
Overall height* of fridge	67 1/2"
Overall width of fridge     Overall width of fridg	31 3/32"
© Depth of fridge door and gasket (excludes handle)	2 3/4"
<ul> <li>Depth of fridge door and chassis (excludes handle)</li> </ul>	27 3/8"
E Depth of fridge chassis (does not include fridge door)	24 5/8"
© Height from bottom datum to top of fridge door	66 9/16"
6 Height of feet (adjustable)	15/16″
<ul> <li>Height from bottom datum to top of top handle</li> </ul>	52 1/2"
<ol> <li>Height from bottom datum to bottom of top handle</li> </ol>	27 3/16"
<ul> <li>Height from bottom datum to bottom of top door</li> </ul>	25 1/16"
Height from bottom datum to top of bottom door     A constraint of the second door     A const	24 1/2"
Height from bottom datum to centerline of bottom handle	22"
<ul> <li>Thickness of handles</li> </ul>	5/8″
<ul> <li>Height from bottom datum to bottom of bottom door</li> </ul>	13/16″
<ul> <li>Depth of handle (measured from front of door)</li> </ul>	1 5/8"
<ul> <li>Depth of door (open at 90°) (measured from front of door)</li> </ul>	13 3/4"
© Depth of drawer (open) (measured from front of drawer) excluding handle	14 3/4"
Rotation of door (open)	138°

\* Includes mounted feet

Minimum Clearances	in
Minimum height of cavity	68 5/16"
Minimum side clearance installed flush with chassis	25/32"
Side clearance - installed flush with door - full rotation	5 5/16"
Rear clearance (including evaporator tray)	1 3/16″


INDICATES PRODUCT DATUM ---INDICATES CABINETRY CLEARANCES -----

### DATE: 06.10.2015

IMPORTANT NOTE: Throughout this guide, dimensions may vary by  $\pm 2mm$ (3/32"). Please read the installation manual for detailed information on installing the product. www.fisherpaykel.com

Fisher&Paykel \_\_\_\_\_

# DATA SHEET



## 790MM ACTIVESMART™ FRIDGE - FRENCH DOOR

(refer page 1 for imperial measurements)

Product Dimensions	mm
Overall height* of fridge	1715
Overall width of fridge	790
© Depth of fridge door and gasket (excludes handle)	70
<ul> <li>Depth of fridge door and chassis (excludes handle)</li> </ul>	695
E Depth of fridge chassis (does not include fridge door)	625
F Height from bottom datum to top of fridge door	1691
Height of feet (adjustable)	24
Height from bottom datum to top of top handle	1333
<ol> <li>Height from bottom datum to bottom of top handle</li> </ol>	691
<ul> <li>④ Height from bottom datum to bottom of top door</li> </ul>	636
Beight from bottom datum to top of bottom door	622
Height from bottom datum to centreline of bottom handle	559
Thickness of handles	16
N Height from bottom datum to bottom of bottom door	16
<ul> <li>Depth of handle (measured from front of door)</li> </ul>	41
Depth of door (open at 90°) (measured from front of door)	350
<ul> <li>Depth of drawer (open) (measured from front of drawer) excluding handle</li> </ul>	375
Rotation of door (open)	138°

\* Includes mounted feet

mm
1735
20
135
30

#### INDICATES PRODUCT DATUM ----INDICATES CABINETRY CLEARANCES -----

### DATE: 06.10.2015

IMPORTANT NOTE: Throughout this guide, dimensions may vary by  $\pm 2mm$ (3/32"). Please read the installation manual for detailed information on installing the product. www.fisherpaykel.com

Fisher&Paykel \_\_\_\_\_