




Door Installation for Reach in Models RIR and RIF Series



The lower hinge and the square hole on the door are clamped



Fix the screws



Fix the upper cover and shutter



Fix the screws



The lower hinge and the square hole on the door are clamped