



BOTTOM MOUNT FRENCH DOOR REFRIGERATOR


MODELS:

WRF535SWBW00 (White)

WRF535SWBB00 (Black)

WRF535SWBM00 (Monochromatic Stainless Steel)

CABINET PARTS




CABINET PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10597594	Use and Care Guide
	W10653003	Energy Guide
	W10517966N	Tech Sheet
2		Cabinet (Not a Servicable Part)
3		Cover, Left Hinge
	12962301W	White
	12962301B	Black
	12962301AP	Grey
4	B5759655	Gasket
5	W10208593	Guard, Dual Water Valve
6	W10141622	Brake, Roller
7		Hinge, Top
	12963204EDN.	Left Hand
8	W10528513	Sweep, Dual Tube
9	12992602	Screw
10		Cover, Right Hinge
	12962302WN	White
	12962302BN	Black
	12962302APN.	Grey

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
11	12990101	Screw
12	12698403	Plate, Pivot
13	12726003	Cover, Water Line
14	12992403	Screw
15		Hinge, Center (Left)
	13000001WD	White
	13000007ED	Black
	13000001AP	Grey
16		Hinge, Top
	12963205EDN.	Right Hand
17		Cover, Corner
	12587703W	White
	12587703B	Black
	12587703AP	Grey
18	W10658542	Block, Fill Tube
19		Assembly, Roller
	W10515763	Left Hand
	W10515762	Right Hand
20	12991302	Screw
21	W10211855	Cover, Unit

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
22		Grille, Toe
	W10534154	White
	W10534153	Black
	W10534155	Grey
23	12990302	Screw
24	M0108107	Clamp, Tube
25	12990511	Screw
26	12820505	Insulation
27	12990504	Screw
28		Shim, Top Hinge
	12999501	Left Hand
	12999502	Right Hand
29		Hinge, Center (Right)
	13000002WD	White
	13000008ED	Black
	13000002AP	Grey


FREEZER LINER PARTS



FREEZER LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	14	W10277025	Module, Light	25		Bracket, Door
2	A3189392	Gasket, Foam	15	13058002	Clip, Evaporator Motor		W10330991	Left Hand
3	12932103	Guide, Fill Tube	16	12466105	Switch, Light		W10330993	Right Hand
4	W10157765	Diverter, Air	17		Rail, Side	26	12990521	Screw
5	W10128551	Motor, Evaporator		W10516603	Left Hand	27		Cradle, Basket
6	12570701	Socket, Light		W10516602	Right Hand		W10280608	Left Hand
7	12002497	Gear	18	W10585187	Funnel, Drain		W10280613	Right Hand
8	12815301	Cover, Thermistor	19	M0500703	Seal	28	W10120018	Slide, Door
9	W10565137	Lamp, LED	20	A3189397	Gasket, Foam	29		Adapter, Slide
10	W10277466	Foil, Housing	21	B8381501	Gasket, Drain		W10284684	Left Hand
11	W10308416	Cover, Evaporator	22	13024803	Grille, Freezer Air		W10284685	Right Hand
12	12990511	Screw	23	13057901	Shroud, Evaporator	30	12990501	Screw
13	W10121318	Grommet	24	2169142	Blade, Fan	31	12812903WD	Shaft, Rack
						32	12791409SP	Thermistor

FREEZER DOOR PARTS




FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Freezer
	12977864W	White
	12977865B	Black
	12977864S	Stainless

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
2		Handle, Door
	W10557414	White
	W10557415	Black
	W10557413N	Stainless

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
3		Gasket, Door
	W10443319	White
	W10436252	Black
	W10443320	Grey
4	W10460893	Screw


REFRIGERATOR LINER PARTS



REFRIGERATOR LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	15	W10594330	Damper, Control	29	12251001	Clip, Water Tube
2	W10464764	Module, Light	16	W10336197	Filter, Water	30	W10533435	Insulation, Water Tank
3	W10613576	Overlay, Control	17	12861601	Switch, Energy Saver	31	B8390302	Clip, Facade
4	W10464775	Module, Control	18	61006182	Union, Water	32	12707005	Facade, Dispenser (Top)
5	W10503278	Control, Electronic	19	W10553467	Tank, Water			Following Parts Not Illustrated
6	C3680310V	Switch, Light	20	12990513	Screw	W10389967		Harness, Controls (Refrigerator)
7	12806501N	Cover, Light	21	12664501SP	Cartridge, Bypass			
8	W10443023	Housing, Light	22	12704801	Plate, Filter			
9	W10565137	Lamp, LED	23	W10605367	Head, Water Filter			
10	12570701V	Socket, Light	24	12568001	Cover, Filter			
11	12806801	Insert, Damper Cover	25	12575501	Switch, Limit			
12	12990604	Screw	26	W10585703	Facade, Dispenser			
13	12806701	Cover, Damper	27	W10585699	Plate, Dispenser			
14	13012402	Insulation, Damper	28	12707206	Guide, Waterline			

REFRIGERATOR DOOR PARTS




REFRIGERATOR DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Left
	13107881W	White
	13107881B	Black
	13107881S	Stainless
2		Door, Right
	13107855W	White
	13107855B	Black
	13107855S	Stainless
3		Closure, Door
	12028505W	White
	12028505B	Black
4	W10460893	Screw
5	W10371194	Bucket, Medium
	W10289497	Bucket, Gallon

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
6		Mullion, Door
	12722803WN	White
7	12990204	Screw
8		Gasket, Door
	W10443221	White
	W10435968	Black
	W10443225	Grey
9		Handle, Door
	W10589564	White
	W10589563	Black
	W10572632N	Stainless
10	12990504	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
11		Stop, Door
	12968202W	White
	12968202B	Black
	12968202AP	Grey
12		Nameplate
	W10391355	White
	W10393265	Grey


UNIT PARTS



UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	12992301	Screw	17	10835903SP	Grommet, Compressor	31	W10189184	Shroud, Condenser Fan
2	12825803	Blade, Fan	18	W10346415	Condenser	32	W10622099	Extension, Drain Tube
3	W10480111	Basepan	19	W10281329	Clip, Drier	33	2319835	Grommet, Condenser
4	12990511	Screw	20	W10292803	Tray, Drip			
5	W10350564	Capacitor	21	12990701	Screw			Following Parts Not Illustrated
6	W10233569	Tube, Discharge	22	W10317014	Evaporator		978025	Valve, Access
7	W10292244	Harness, Evaporator (Includes Heater)	23		Dam		978026	Valve, Access
8	W10296785	Pan, Drain		12225702	Right Hand		978027	Valve, Access
9	W10622701	Screw		12225602	Left Hand		978028	Valve, Access
10	12729129	Heater, Defrost	24	W10239053	Motor, Fan		978029	Valve, Access
11	W10216075	Strap, Bale	25	10428101	Clip, Heater		978030	Valve, Access
12	W10330834	Device, Start	26	W10234031	Harness, Unit (Includes Power Cord)		876764	Valve, Access
13	W10137529	Grommet, Condenser	27	W10177049	Drier			REFRIGERANT CHARGE 5.00 oz. (R-134A)
14	W10236396	Strap, Compressor	28	W10445422	Compressor			
15	12477102	Roller	29	10623002	Clip, Evaporator			
16	12992101	Screw	30	12477202	Axle, Roller			


SHELF PARTS



SHELF PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	12204830	Glass, Shelf	16		Endcap, Pantry	31	12656813	Lid, Pantry
2	W10596756	Assembly, Produce Preserver		12656106	Left Hand	32	W10503184N	Basket, Freezer (Lower)
3	W10149389N	Lift, Bail Arm		12656019	Right Hand	33	W10146440N	Divider, Basket (Lower)
4	W10528935	Trim, Pantry Glass	17	12804601SP	Pan, Crisper	34	W10348246	Basket, Freezer (Upper)
5	12227305WH	Brace, Pantry	18	12642303WD	Brace, Crisper Cover	35		Gear, Spur
6	12531901	Track, Deli Drawer	19	W10231345N	Trim, Crisper		W10474715	Right Hand
7	W10171558	Divider, Basket (Upper)	20	W10329866	Frame, Crisper		W10474716	Left Hand
8	W10241046	Divider, Basket (Upper)	21	12204824N	Glass, Crisper	36	W10326469N	Rail, Center Crisper
9	12656901	Gasket, Pantry	22	W10273463	Ladder, Center	37	12812904WD	Shaft, Rack
10	12656202	Housing, Control	23	W10569182	Ladder, Side	38		Mount, Gear
11	W10590947	Shelf, Fixed	24	12990513	Screw		W10348260	Right Hand
12	12655402	Slide, Temperature Control	25	W10215666	Screw		W10348259	Left Hand
13	12990512	Screw	26	12990504	Screw	39	12802602SP	Front, Crisper Pan
14	W10235370	Glide, Pantry	27	12530805SP	Slide, Humidity Control	40	13062602	Support, Crisper Frame
15	12990513	Screw	28	12655304	Bar, Control	41	13025201N	Tray, Lower
			29	12731302	Drawer, Pantry			
			30	12655204	Knob, Temperature Control			

ICEMAKER PARTS



ICEMAKER PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	2256086	Bracket, Ice Maker
2	B5705333	Tubing, Plastic
3	10526702	Clamp, Wire
4	W10001240	Screw
5	W10420083	Valve, Water Inlet
6	W10512602	Arm, Shut Off
7	W10377174	Cover, Front
8	A3223101	Insert, Tube
9	W10300025	Assembly, Mold and Heater

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
10	W10410073	Cup, Water Fill
11	W10318914	Ejector, Arm
12	W10122563	Stripper, Ice
13	W10528513	Sweep, Dual Tube
14	628379	Clip, Thermal Fuse
15	W10290336	Thermostat
16	8533917	Screw
17	489464	Screw
18	W10458985	Harness, Ice Maker

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
19	M0114003	Clip, Speed
20	W10281342	Assembly, Module And Motor
21		Motor (Not Available, Order Item #20)
22	W10171529N	Pan, Ice
23	10463203	Elbow, Fill Tube
100	W10469286	Assembly, Icemaker (Complete)

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	511873	White Porcelain (2 oz.)
	4392899	Biscuit/Bisque

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350939	Enamel, Black
	285006	Black
	350942	White Primer
	4392901	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White

MISCELLANEOUS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876370	Insulation (2 Pieces, 3" x 24" x 48")
	876305	Insulation Kit (14 Pieces, 3" x 24" x 48")
	978941	Insulation, Fiberglass (63 1/2" x 35 1/2" x 2 5/8")
	876029	Kit, Foam Slab (30" x 32 1/2" x 1 1/2")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	20000008	Cleaner, Stainless Steel
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	833938	Kit, Terminal Connector

TORX SCREW WRENCH

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key