

ANDROID AMAZON ALEXA APP CONNECT GUIDE

The instructions in this document are for our current models, which use the SHARP HOME™ App. To confirm which app your product uses, please refer to your product's Pairing Guide. If your product uses the Sharp Kitchen App, please refer to page 3 for instructions.






Please ensure that you have downloaded the SHARP HOME™ App and have paired with your appliance. Once the appliance has been paired to the SHARP HOME™ App, follow below steps to enable the SHARP HOME - Kitchen Skills in the Alexa App. For a full list of commands for your appliance, please refer to our Alexa Skill Command Guide.

Step 1: Download and sign-in to the Amazon Alexa App.

Step 2: Tap the menu icon in the top left corner and then tap "Alexa+ Store".

Step 3: Tap the magnify glass and search for "SHARP HOME".

Step 4: Scroll down to "Original Skills" and select "SHARP HOME - Kitchen".







ANDROID AMAZON ALEXA APP CONNECT GUIDE

Step 5: Tap on “Enable To Use.”

Step 6: Tap on “Allow”

Step 7: Log in using your Sharp account ID to complete the set up.



IOS AMAZON ALEXA APP CONNECT GUIDE

The instructions in this document are for our current models, which use the SHARP HOME™ App. To confirm which app your product uses, please refer to your product's Pairing Guide. If your product uses the Sharp Kitchen App, please refer to page 3 for instructions.






Please ensure that you have downloaded the SHARP HOME™ App and have paired with your appliance. Once the appliance has been paired to the SHARP HOME™ App, follow below steps to enable the SHARP HOME - Kitchen Skills in the Alexa App. For a full list of commands for your appliance, please refer to our Alexa Skill Command Guide.

Step 1: Download and sign-in to the Amazon Alexa App.

Step 2: Tap the menu icon in the top left corner and then tap "Alexa+ Store".

Step 3: Tap the magnify glass and search for "SHARP HOME".






IOS AMAZON ALEXA APP CONNECT GUIDE

Step 4: Scroll down to “Original Skills and select “SHARP HOME - Kitchen”.

Step 5: Tap on “Enable To Use.”

Step 6: Log in using your Sharp account ID to complete the set up.



ANDROID AMAZON ALEXA APP CONNECT GUIDE







Please ensure that you have downloaded the Sharp Kitchen App and have paired with your appliance. Once the appliance has been paired to the Sharp Kitchen app, follow below steps to enable the Sharp Kitchen Skills in the Alexa App. For a full list of commands for your appliance, please refer to our Alexa Skill Command Guide.

Step 1: Download and sign-in to the Amazon Alexa App.

Step 2: Tap the menu icon in the top left corner and then tap "Alexa+ Store".

Step 3: Tap the magnify glass and search for "Sharp Kitchen".




Step 4: Scroll down to "Original Skills" and select "Sharp Kitchen".



ANDROID AMAZON ALEXA APP CONNECT GUIDE

Step 5: Tap on “Enable To Use.”

Step 6: Log in using your Sharp account ID to complete the set up.



IOS AMAZON ALEXA APP CONNECT GUIDE






Please ensure that you have downloaded the Sharp Kitchen App and have paired with your appliance. Once the appliance has been paired to the Sharp Kitchen app, follow below steps to enable the Sharp Kitchen Skills in the Alexa App. For a full list of commands for your appliance, please refer to our Alexa Skill Command Guide.

Step 1: Download and sign-in to the Amazon Alexa App.

Step 2: Tap the menu icon in the top left corner and then tap "Alexa+ Store".

Step 3: Tap the magnify glass and search for "Sharp Kitchen".



IOS AMAZON ALEXA APP CONNECT GUIDE

Step 4: Scroll down to “Original Skills” and select “Sharp Kitchen”.

Step 5: Tap on “Enable To Use.”

Step 6: Log in using your Sharp account ID to complete the set up.

