

iOS GOOGLE HOME APP CONNECT GUIDE






Please ensure that you have downloaded the SHARP HOME™ App and have paired with your appliance. Once the appliance has been paired to the SHARP HOME™ App, follow below steps to enable the SHARP HOME™ Skills in the Google Home App. For a full list of commands for your appliance, please refer to our Google Command Guide.

Step 1: Download and sign-in to the Google Home App.

Step 2: Tap the + icon in the top right corner and then tap “Link app or service”.

Step 3: Tap “Works with Google”.






iOS GOOGLE HOME APP CONNECT GUIDE

Step 4: Tap the magnify glass and search for "SHARP HOME".

Step 5: Tap "SHARP HOME - Kitchen".

Step 6: Tap "Continue".






iOS GOOGLE HOME APP CONNECT GUIDE

Step 7: Tap “Agree and continue”.

Step 8: Tap “Allow”. (You may press “Terms and Condition Privacy Policy” to review before pressing “Allow”)

Step 9: Log in using your Sharp account ID to complete the set up.

Step 10: Follow the remaining prompts to finish connecting your product with the Google Home app.



To maintain the connection between the SHARP HOME™ App and the Google Home App, users will need to reset and relink this connection to the Google Home App every 180 days. For reset and relinking instructions, please refer to the Google Home Account Relink Guide on page 10.

ANDROID GOOGLE HOME APP CONNECT GUIDE






Please ensure that you have downloaded the SHARP HOME™ App and have paired with your appliance. Once the appliance has been paired to the SHARP HOME™ App, follow below steps to enable the SHARP HOME™ Skills in the Google Home App. For a full list of commands for your appliance, please refer to our Google Command Guide.

Step 1: Download and sign-in to the Google Home App.

Step 2: Tap the + icon in the top right corner and then tap “Link app or service”.

Step 3: Tap “Works with Google”.






ANDROID GOOGLE HOME APP CONNECT GUIDE

Step 4: Tap the magnify glass and search for "SHARP HOME".

Step 5: Tap "SHARP HOME - Kitchen".

Step 6: Tap "Continue".






ANDROID GOOGLE HOME APP CONNECT GUIDE

Step 7: Tap “Agree and continue”.

Step 8: Tap “Allow”. (You may press “Terms and Condition Privacy Policy” to review before pressing “Allow”)

Step 9: Log in using your Sharp account ID to complete the set up.

Step 10: Follow the remaining prompts to finish connecting your product with the Google Home app.



To maintain the connection between the SHARP HOME™ App and the Google Home App, users will need to reset and relink this connection to the Google Home App every 180 days. For reset and relinking instructions, please refer to the Google Home Account Relink Guide on page 7.




ANDROID GOOGLE HOME ACCOUNT RELINK GUIDE

To maintain the connection between the SHARP HOME™ App and the Google Home App, users will need to reset and relink this connection to the Google Home App every 180 days. Follow the steps below to reset and relink your connection.

Step 1: Open the Google Home app.

Step 2: Tap the + icon in the top right corner and then tap “Device”.

Step 3: Tap “Link apps or services”.







ANDROID GOOGLE HOME ACCOUNT RELINK GUIDE

Step 4: Tap the magnify glass and search for "SHARP HOME".

Step 5: Tap "SHARP HOME - Kitchen".

Step 6: Tap "Reconnect account".

Step 7: Tap "Continue"






ANDROID GOOGLE HOME ACCOUNT RELINK GUIDE

Step 8: Tap “Agree and continue”.

Step 9: Tap “Allow”. (You may press “Terms and Condition Privacy Policy” to review before pressing “Allow”)

Step 10: Log in using your Sharp account ID to complete the set up.

Step 11: Follow the remaining prompts to finish relinking with the Google Home app.






iOS GOOGLE HOME ACCOUNT RELINK GUIDE

To maintain the connection between the SHARP HOME™ App and the Google Home App, users will need to reset and relink this connection to the Google Home App every 180 days. Follow the steps below to reset and relink your connection.

Step 1: Open the Google Home app.

Step 2: Tap the + icon in the top right corner and then tap “Device”.

Step 3: Tap “Link apps or services”.







iOS GOOGLE HOME ACCOUNT RELINK GUIDE

Step 4: Tap the magnify glass and search for "SHARP HOME".

Step 5: Tap "SHARP HOME - Kitchen".

Step 6: Tap "Check for new devices".

Step 7: Tap "Continue".



iOS GOOGLE HOME ACCOUNT RELINK GUIDE

Step 8: Tap “Agree and continue”.

Step 9: Tap “Allow”. (You may press “Terms and Condition Privacy Policy” to review before pressing “Allow”)

Step 10: Log in using your Sharp account ID to complete the set up.

Step 11: Follow the remaining prompts to finish relinking with the Google Home app.

