

CORNUFÉ SERIES CLEANING TIPS

LA CORNUÉ

CORNUFÉ

CLEANING SUPPLIES

NAME BRAND CLEANING SUPPLIES:

Windex Cleaner®
Bon Ami®
Barkeepers Friend®
Weiman Stainless Steel Disposable Wipes®

The following brand name products are available online:

Dawn Power Dissolver®
<https://www.pjmarketplace.com/dawn-power-dissolver-6-pack-32oz.html>

PLEASE NOTE: This product can only be purchased online at [pjmarketplace.com](https://www.pjmarketplace.com)

Scotch-Brite®
3M 07447 Scotch-Brite® Maroon General Purpose Hand Pad, 20 Pack
<https://tcpglobal.com/products/mmm-7447>

PLEASE NOTE: This product can be purchased online at tcpglobal.com

Option to be used with hand pad above:

Twist-Lok Pad Holder in Gray by Magellan Distribution Corporation
https://www.amazon.com/dp/B000JKAIVW/ref=cm_sw_em_r_mt_dp_U__c2ReCbYC8DB6V

PLEASE NOTE: This product can be purchased online at [amazon.com](https://www.amazon.com)

Cape Cod Polish Co. Metal Polishing Cloths Tin (*polishing wipes and creams*)
https://www.amazon.com/dp/B0102K3NLU/ref=cm_sw_em_r_mt_dp_9MDDA9F73H59PTAQJQ2A

PLEASE NOTE: This product can be purchased online at [amazon.com](https://www.amazon.com)

GENERAL CLEANING SUPPLIES:

Microfiber Cloths
Non-Abrasive Sponge
Paper Towels
White Vinegar
Mild Dish Soap
Rubber Cleaning Gloves [Use with Dawn Power Dissolver®]



PANEL CLEANING:

POLISHED ENAMEL PANELS (ALL COLORS EXCEPT MATTE FINISHES):

Apply warm and mild soapy water to a microfiber cloth and agitate to remove grease or food stains. Promptly dry area with a clean microfiber cloth. Windex® can be used as an alternative to optimize shine when applied to a clean microfiber cloth first. Never spray Windex® (or any cleaner) directly onto enameled surfaces.

MATTE ENAMEL PANELS:

Apply warm and mild soapy water to a microfiber cloth and gently agitate to remove grease or food stains. Promptly dry area with a clean microfiber cloth.

BRUSHED STAINLESS STEEL:

Stainless Steel may darken over time. To restore luster, clean with Stainless Steel Wipes; we recommend Weiman Stainless Steel Disposable Wipes®. Use a clean microfiber cloth to remove any remaining residue.

ACCENTS:

POLISHED BRASS:

Be sure to have a good supply of clean microfiber cloths on hand. Brass trim on CornuFé ranges are not lacquered and will patina naturally. Patina can be removed with brass polish; we recommend Cape Cod Polish. Follow manufacturer instructions provided with product. Apply polish to clean microfiber cloth and coat a small area. Do not allow polish to dry or remain on surface for extended periods of time. Use a clean microfiber cloth to remove any remaining residue.

CHROME:

Polished Chrome and Polished Stainless Steel are low-maintenance and require little polishing, if any. As needed, clean with Windex® or Weiman® Stainless Steel Wipes. Use a clean microfiber cloth to remove any remaining residue.



GAS COOKTOP:

BURNERS GRATES:

Apply warm and mild soapy water to a microfiber cloth and agitate to remove grease or food stains. Promptly dry area with a clean microfiber cloth. Dawn Power Dissolver® can be used for stubborn areas.

GAS BURNER CAPS:

To remove burnt on grease, wash with warm soapy water. Make sure that all holes around the cap are free of grease and food debris.

**Allow enough time for the piece to cool before handling. Rinse and dry. To obtain a shine, use MAAS® metal Polish with a dry microfiber cloth.*

STAINLESS STEEL COOKTOP:

Scratches may appear over time. Using a maroon Scotch-Brite® pad (holder recommended) ***gently rub parallel to grain***. Use a ***stainless steel wipe*** to remove any residue from pad.



INDUCTION COOKTOP:

Weiman Glass Cook Top Cleaner is an excellent cleaner for the induction cooktop. Follow the manufacturer instructions for use on the cooktop and inner glass door of the CornuFe 90 units. Please note if you purchase the Weiman Glass Cook Top Cleaner kit, it will come with a stainless razor blade to use to remove burnt on spots from the glass surface. It is safe to use but it is important to be careful when using around the rubber gasket of the oven doors. If you don't feel comfortable using this, we also recommend using a plastic razor blade to remove the burnt-on spots from the glass surface, one can be found using this link: <https://a.co/d/chwllf7>



O V E N S :

Use a sponge and warm soapy water to remove any splatters of food or grease. The oven may be warmed slightly before cleaning to soften baked-on foods and grease. For baked on grease be sure to use Dawn Power Dissolver®. (Spray and let it sit for about ten to fifteen minutes.) Use a damp clean microfiber cloth to remove. Never use any abrasive cleaner (such as Comet®) as these products may compromise the enamel seal. Dawn Power Dissolver® can also be used on oven accessories such as oven racks, roasting dish, and trays. Be sure to rinse thoroughly.

