


# PRW15C01CG

Presrv™ Single Zone Wine Cooler

# ZEPHYR



## PRW15C01CG

| Ref # | Part #   | Description              | Qty. |
|-------|----------|--------------------------|------|
| 1     | 56300003 | Dryer Filter             | 1    |
| 2     | 11030118 | Power Cord               | 1    |
| 3     | 56220051 | Anti Vibration Gasket    | 2    |
| 4     | 56130043 | Drip Tray                | 1    |
| 5     | 12160008 | Compressor               | 1    |
| 5-1   | 12050048 | Compressor Capacitor     | 1    |
| 6     | 11050028 | Compressor Starter       | 1    |
| 7     | 11050029 | Compressor Relay         | 1    |
| 8     | 11030119 | Compressor Ground Wire   | 1    |
| 9     | 50330010 | Sealing Tube             | 1    |
| 10    | 56200121 | Main PCB Box             | 1    |
| 11    | 11010174 | Main Power Control Board | 1    |
| 13    | 56210075 | Decorative Hole Cover    | 6    |
| 14    | 54180072 | Upper Right Hinge        | 1    |
| 14-1  | 01020066 | Hinge Screw              | 3    |
| 15    | 50330037 | Door Axis Pin            | 2    |
| 16    | 54240005 | Evaporator               | 1    |
| 17    | 56180015 | Evaporator Foam          | 2    |
| 18    | 12130043 | Evaporator Fan Assembly  | 1    |
| 19    | 54170023 | Air Duct Board           | 1    |
| 20    | Z0F-C004 | Carbon Filter            | 1    |
| 21    | 54210017 | Fan Cover                | 1    |
| 22    | 12010018 | LED Light                | 1    |
| 23    | 52150017 | LED Light Cover          | 1    |
| 24    | 56200124 | Display Box              | 1    |
| 25    | 11010170 | Display Control Board    | 1    |
| 26    | 52050030 | Display Panel            | 1    |
| 27    | 54210038 | Door Axis Cover          | 2    |

|      |          |                          |   |
|------|----------|--------------------------|---|
| 28   | 54220011 | Magnet                   | 1 |
| 28-1 | 54140247 | Magnet Bracket           | 1 |
| 29   | 54050093 | Door Lock Plate          | 1 |
| 30   | 50230036 | Door                     | 1 |
| 31   | 50280003 | Handle                   | 1 |
| 32   | 56220058 | Door Gasket              | 1 |
| 33   | 50150038 | Wooden Shelf             | 6 |
| 35   | 50320040 | Shelf Slider Set         | 6 |
| 36   | 54210014 | Sensor Cover             | 1 |
| 37   | 11050008 | Sensor                   | 1 |
| 38   | 11050007 | Sensor                   | 1 |
| 39   | 50260023 | Kick Plate               | 1 |
| 39-1 | 01020073 | Kick Plate Screw         | 5 |
| 40   | 11040033 | Magnetic Switch          | 1 |
| 41   | 15000019 | Door Lock Key            | 2 |
| 42   | 50180006 | Door Lock                | 1 |
| 43   | 54180073 | Lower Right Hinge        | 1 |
| 43-1 | 01020066 | Hinge Screw              | 3 |
| 44   | 50350008 | Leveling Leg             | 4 |
| 45   | 54140294 | Cabinet Bottom Bracket   | 1 |
| 45-1 | 01060015 | Cabinet Bracket Screw    | 4 |
| 46   | 56140022 | LED End Cap              | 4 |
| 46-1 | 01020065 | Screw Cover              | 4 |
| 47   | 12010019 | LED Light Assembly       | 2 |
| 48   | 54270005 | Condensor                | 1 |
| 49   | 54210018 | Condensor Cover          | 1 |
| 50   | 50330033 | Capillary Tube           | 1 |
| 51   | 54190068 | Compressor Support Plate | 1 |
| 51-1 | 01060015 | Support Plate Screw      | 4 |
| 52   | 12130043 | Fan                      | 1 |
| 52-1 | 54210016 | Fan Cover                | 1 |
| 53   | 50330032 | Connecting Pipe          | 1 |

|    |          |               |   |
|----|----------|---------------|---|
| 54 | 50330025 | Water Pipe    | 1 |
| 55 | 00100030 | Hex Wrench M3 | 1 |

OCT25.0201