

# Door reversal

---

## First Step Door removal

Tilt Unit back, take off the two Phillips head screws and remove the door bottom hinge

Once the bottom hinge is removed, proceed by taking the door away from the unit

Remove the door handle

Disassemble the unit top cover by removing two screws located behind the unit

Remove 3 screws to take out the top metal plate in the front above the door

Remove the 2 screws to take out the upper hinge

## Installing the door in opposite side

---

Install the upper hinge in the opposite side ( 2 screws )

Install the metal plate that covers the upper hinge ( 3 screws )

Remove the plastic plugs on the side of the door, to install handle in the other side, ( these plugs must be saved to cover the holes where the handle was previously mounted )

Install the door in the opposite side, in some cases you may need to remove and change the position of the plastic plug that was covering the door mounting holes

Change the position of the bottom support and bottom hinge

Then proceed by aligning the door before having the bottom hinge totally tight