

KitchenAid®

Mixer




Cordless Hand Mixer - battery sold separately

MODELS:

KHMR700BM0 (Black Matte)

KHMR700SE0 (Shaded Palm)

UNIT PARTS



UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W11634658	Use & Care Guide
2	W11697803	Beaters