




## **30" ELECTRIC FREESTANDING STANDARD CLEAN RANGE**

### **MODELS:**

WFE550S0HB1 (Black)  
WFE550S0HW1 (White)


# COOKTOP PARTS



# COOKTOP PARTS

| <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u>          | <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u>               | <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u>                         |
|-------------------|-----------------|-----------------------------|-------------------|-----------------|----------------------------------|-------------------|-----------------|--|
| 1                 |                 | Literature Parts            | 5                 | W10275048       | Element (3000/1400W)             | 11                | W10248261       | Element (1200W)<br>(Left Rear, Right Rear) |
|                   | W11157404       | Instructions, Installation  |                   |                 | (Left Front)                     |                   |                 | FOLLOWING PARTS<br>NOT ILLUSTRATED         |
|                   | W11102909       | Use and Care Guide          |                   | W10711900       | Element (3000W)<br>(Right Front) |                   | W11134843       | Harness, Main                              |
|                   | W11102747       | Sheet, Tech                 | 6                 | 3196169         | Screw                            |                   | W11134592       | Harness, Warm Zone                         |
|                   | W11109899       | Wiring Diagram              | 7                 | W10691223       | Pan, Radiant Element             |                   | W11134603       | Harness, Cooktop<br>(Left)                 |
| 2                 | W10225448       | Spring, Element             | 8                 | W10306542       | Bracket, Anti-Tip                |                   | W11134845       | Harness, Cooktop<br>(Right)                |
| 3                 | W10607641       | Bracket, Cooktop<br>(Left)  | 9                 | 7101P485-60     | Screw, Anti-Tip Kit              |                   | W11172528       | Harness, Hidden Bake                       |
|                   | W10607642       | Bracket, Cooktop<br>(Right) | 10                | W10799048       | Element, Warm Zone<br>(Center)   |                   | W10183541       | Clip, Spring Steel                         |
| 4                 |                 | Cooktop                     |                   |                 |                                  |                   | 3196520         | Clip, Wire                                 |
|                   | W11034836       | Black                       |                   |                 |                                  |                   |                 |  |
|                   | W11034832       | White                       |                   |                 |                                  |                   |                 |  |


# CONTROL PANEL PARTS



# CONTROL PANEL PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>        | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>           | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>        |
|-----------------------------|-----------------|---------------------------|-----------------------------|-----------------|------------------------------|-----------------------------|-----------------|---------------------------|
| 1                           |                 | Endcap                    | 4                           | W10434452       | Switch, Infinite (Dual)      | 9                           | 3400882         | Screw                     |
|                             | W11213290       | Black (Left)              |                             |                 | (Left Front and Right Front) | 10                          | 8272473         | Cover, Upper Rear         |
|                             | W11213292       | Black (Right)             |                             |                 |                              | 11                          | W10525121       | Bracket, Console Mounting |
|                             | W11213291       | White (Left)              |                             | 3148951         | Switch, Infinite             | 12                          |                 | Bracket, Eye Brow         |
|                             | W11213293       | White (Right)             |                             |                 | (Right Rear and Left Rear)   |                             | W11051312       | Black                     |
| 2                           |                 | Control, Electronic (LCX) | 5                           | 3196178         | Screw                        |                             | W11051311       | White                     |
|                             | W11204529       | Black                     | 6                           | W10856361       | Bracket, Control             | 13                          | W10901802       | Panel, Backer             |
|                             | W11204530       | White                     | 7                           |                 | Knob                         | 14                          | 3196169         | Screw                     |
| 3                           |                 | Console, Assembly         |                             | W11022718       | Black                        |                             |                 |                           |
|                             | W11089991       | Black                     |                             | W11022720       | White                        |                             |                 |                           |
|                             | W11089992       | White                     | 8                           | W10134247       | Shield, Heat                 |                             |                 |                           |


# CHASSIS PARTS



# CHASSIS PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>          | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>           | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>              |
|-----------------------------|-----------------|-----------------------------|-----------------------------|-----------------|------------------------------|-----------------------------|-----------------|---------------------------------|
| 1                           | W10289077       | Receiver, Hinge             | 18                          | 3196172         | Screw                        | 37                          | 9761013         | Assembly, Door Latch (Front)    |
| 2                           | 3196154         | Screw                       | 19                          | W10404688       | Clip, Oven Support           | 38                          | 3196560         | Screw                           |
| 3                           |                 | Panel, Side                 | 20                          | 3186034         | Bracket, Service             | 39                          | W10078380       | Rod, Latch                      |
|                             | W10162245       | Black                       | 21                          | W10245259       | Block, Terminal              | 40                          | W10107820       | Assembly, Door Latch (Rear)     |
|                             | W10575396       | White                       | 22                          | 3400968         | Nut                          | 41                          | W10268578       | Rack, Oven                      |
| 4                           | 3400029         | Nut                         | 23                          | 3196178         | Screw                        | 42                          | W11190726       | Fan, Convection                 |
| 5                           | W10658354       | Seal, Door                  | 24                          | W11175594       | Assembly, Light              | 43                          | W10116351       | Blade, Fan                      |
| 6                           | 9757340         | Element, Broil              | 25                          | W10571723       | Bulb, Halogen 40 Watts       | 44                          | W10213748       | Nut                             |
| 7                           | 9755770         | Element, Bake               | 26                          | 3400016         | Screw                        | 45                          | W10134126       | Bracket, Fan                    |
| 8                           | 3196174         | Screw                       | 27                          | W10181986       | Sensor, Oven                 | 46                          | 4449809         | Screw                           |
| 9                           | W10134285       | Tube, Vent                  | 28                          | 3196169         | Screw                        | 47                          | W10134124       | Cover, Conv Fan                 |
| 10                          | W10674705       | Glide, Drawer Front         | 29                          | W10326122       | Cover, Terminal Block        | 48                          | W10183712       | Tray, Hidden Bake               |
| 11                          | W10341186       | Assembly, Front Foot        | 30                          | W10031780       | Screw                        | 49                          | W10134125       | Shield, Heat                    |
| 12                          | W10067840       | Screw                       | 31                          | 9757239         | Rod, Door Switch             | 50                          | W10646923       | Card, Insulator                 |
| 13                          | W10134121       | Tray, Insulation            | 32                          | W11034869       | Screw                        |                             |                 | FOLLOWING PARTS NOT ILLUSTRATED |
| 14                          | W10137382       | Clip, Panel                 | 33                          | W10910404       | Counterweight                |                             | W10774939       | Insulation, Wrap                |
| 15                          | W10390008       | Assembly, Base Rail (Left)  | 34                          | W10627802       | Switch, Door                 |                             | W11127324       | Insulation, Back                |
|                             | W10390007       | Assembly, Base Rail (Right) | 35                          | W10281322       | Kit, Bare Wire Adapter Block |                             | W10333344       | Insulation, Flue                |
| 16                          | W10058460       | Foot, Leveling              | 36                          | W11092984       | Screen, Vent                 |                             |                 |                                 |
| 17                          | 3196548         | Fuse, Thermal               |                             |                 |                              |                             |                 |                                 |

# DOOR PARTS




# DOOR PARTS

| <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u>                  |
|-------------------|-----------------|-------------------------------------|
| 1                 |                 | Trim, Top                           |
|                   | W10310922       | Black                               |
|                   | W10310920       | White                               |
| 2                 | W10480830       | Screw                               |
| 3                 |                 | Handle, Door<br>(Includes Standoff) |
|                   | W11039068       | Black                               |
|                   | W11039067       | White                               |
| 4                 | 9761344         | Liner, Door                         |
| 5                 | W10031790       | Screw                               |
| 6                 | 9758162         | Glass, Inner                        |
| 7                 | 9761357         | Retainer, Insulation                |
| 8                 | W10299226       | Hinge, Active                       |

| <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u>         |
|-------------------|-----------------|----------------------------|
| 9                 |                 | Glass Assembly, Outer Door |
|                   | W10884159       | Black                      |
|                   | W10409945       | White                      |
| 10                |                 | Trim, Side                 |
|                   | W10746436       | Black (Left)               |
|                   | W10746435       | Black (Right)              |
|                   | 8523172         | White (Left)               |
|                   | 8523166         | White (Right)              |
| 11                | W10327235       | Screw                      |
| 12                |                 | Trim, Lower                |
|                   | 8523177         | Black                      |
|                   | 8523175         | White                      |
| 13                | W10031780       | Screw                      |

| <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u>     |
|-------------------|-----------------|------------------------|
| 14                | W10544179       | Strap, Door            |
| 15                | W10200660       | Screw                  |
| 16                | W10884775       | Nameplate              |
| 17                | W10278991       | Insulation, Door Strip |
| 18                | W10299227       | Hinge, Door (Passive)  |
| 19                | W10316950       | Frame, Glass           |

# DRAWER PARTS



# DRAWER PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>          |
|-----------------------------|-----------------|-----------------------------|
| 1                           | 3196165         | Screw                       |
| 2                           | W10688022       | Drawer, Storage             |
| 3                           | W10462912       | Bracket, Mounting<br>Drawer |

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|--------------------|
| 4                           |                 | Rivet, Push        |
|                             | 3196813         | Black              |
|                             | 3196814         | White              |

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>  |
|-----------------------------|-----------------|---------------------|
| 5                           |                 | Panel, Drawer Front |
|                             | W11123900       | Black               |
|                             | W11123901       | White               |
| 6                           | W10674708       | Glide, Drawer Rear  |

# OPTIONAL PARTS

## REFINISHING MATERIAL

| <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u>        |
|-------------------|-----------------|---------------------------|
|                   | 242756          | Oven Liner Touch Up Paint |

## PAINT, TOUCH-UP (1/2OZ.)

| <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u>      |
|-------------------|-----------------|-------------------------|
|                   | 72017           | White                   |
|                   | 511873          | White Porcelain (2 oz.) |

## PAINT, BULK (1 QT.)

| <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u> |
|-------------------|-----------------|--------------------|
|                   | 799344          | White (Uncut)      |

## INSULATION

| <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u>               |
|-------------------|-----------------|----------------------------------|
|                   | 261514          | Insulation (1-1/2" x 24" x 120") |
|                   | 240132          | Insulation (2-1/2" x 22" x 120") |

## PAINT, PRESSURIZED SPRAY (12 OZ.)

| <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u> |
|-------------------|-----------------|--------------------|
|                   | 350930          | White              |
|                   | 285006          | Black              |
|                   | 206922          | Primer (White)     |

## ACCESSORY PARTS

| <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u>           |
|-------------------|-----------------|------------------------------|
|                   | 4396923         | Grid, Broiler Pan and        |
|                   | W10355016       | Cleaner, Stainless Steel     |
|                   | W10355051       | Cleaner, Cooktop             |
|                   | WA906B          | Scraper, Cooktop             |
|                   | 4396096RB       | Griddle                      |
|                   | 4396923         | Grid, Broiler Pan and        |
|                   | W10123240       | Rack, Broiler Pan & Roasting |