




30" GAS FREESTANDING SELF CLEAN CONVECTION RANGE
Finger Print Resistant

MODELS:

MGR8800FZ1 (Stainless)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	6		Panel, Manifold	15		Bezel
	W11383207	Installation Instructions		W10861559	Stainless		W10876919	Stainless
	W11404102	Use & Care Guide	7		Knob			FOLLOWING PARTS NOT ILLUSTRATED
	W10538797	Tech Sheet		W10858253	Stainless		W10797419	Harness, Main
	W10400066	Quick Start Guide (English)	8		Grate Kit		W10753750	Harness, Bake/Broil
2		Burner Cap Kit		W11241655	Black (Set of 2)		W10334923	Clip, Gas Wiring
	W11352138	Black (Set of 4) (Left Front, Left Rear, Right Front, Right Rear)	9		Hinge, Grate (Not Serviced)		313438	Clip, Harness
			10	W11379946	Manifold Panel Bracket		7111P017-60	Clamp, Wire
			11	W11379358	Rear Gas Cooktop Bracket		3196896	Clip, Wire
3	W10067840	Screw	12	W11379945	Bracket, Anti-Tip		3196520	Clip, Wire
4	W11367106	Burner Kit	13	7101P485-60	Screw, Anti-Tip Kit			
5		Cooktop	14	W10432544	Griddle			
	W11418086	Black						


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap	5	W10198745	Cover, Upper	12	W10475149	Module, Spark (5+0)
	W11130372	Black (Left)	6	W10192841	Shield, Heat	13	W10797001	Bracket, Ignitor
	W11130379	Black (Right)	7	W10340325	Control, MRC	14		Assembly, Active Overlay
2	W10516123	Bracket, Console Mounting	8	W10762981	Bracket, Mounting		W10884364	Black
3		Console	9	W10184251	Cover, Back			
	W10645848	Stainless	10	3196178	Screw			
4	W10920631	Module, Spark DSI	11	W10551614	Spreader, Clip-Spring			


CHASSIS PARTS



CHASSIS PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10314347	Assembly, Flue	17	W10362924	Screw	32	W10031790	Screw
2	9758701	Spacer, Door	18	W10323077	Diffuser, Flame	33	W10874067	Motor, Fan (Convection)
3	W10273002	Bracket, Oven Support	19	3196178	Screw	34	W10346154	Cover, Convection
4		Panel, Side	20	W10531060	Rack, Oven	35	W10362924	Screw
	W10162245	Black	21	W10162385	Gasket, Door	36	W10289145	Rack, Oven (Gull-Wing)
5	W10158780	Cover, Rear Fan	22	W10031780	Screw			FOLLOWING PARTS NOT ILLUSTRATED
6	W10627802	Switch, Door	23	W10273195	Shield, Heat			
7	W10137382	Clip, Panel	24	W11370463	Rod, Door Switch			
8	W10501599	Clip, Front Frame Cover	25	W10624590	Cord, Power			
			26	W10035900	Support, Oven Bottom			4820F015-59 Insulation, Strap
9	W10289077	Receiver, Hinge	27	W11379356	Pan, Bake			W10526208 Insulation, Wrap
10	W10058460	Foot, Leveling	28	W11175594	Light Assembly			W10526209 Insulation, Main Back
11	W10211368	Bottom, Oven	29	W10571723	Bulb, Halogen 40 Watts			
12	W10586204	Sensor						
13	3601P356-45	Baffle, Bake Burner	30	W10341186	Front Foot Assembly			
14	3196178	Screw	31	W10390008	Base Rail Assembly (Left)			
15	W10435470	Brace, Main Back						
16	W11040249	Assembly, Flue (Upper)		W10390007	Base Rail Assembly (Right)			


MANIFOLD PARTS



MANIFOLD PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10295997	Screw, Valve	8	W11352012	Valve, Gas (Left Front & Right Front)	18	3196178	Screw
2	W11331179	Orifice Holder Assembly (18K) (Left Front)		W11352013	Valve, Gas (Left Rear, Center)	19	3196385	Screw
	W11345009	Orifice Holder Assembly (9.5K) (Left Rear)		W11352015	Valve, Gas (Right Rear) (Center)	20	3400016	Screw
	W11345011	Orifice Holder Assembly (15K) (Right Front)	9	W10224921	Bracket, Aegis	21	W11428831	Electrode (Left Front, Left Rear)
	W11345010	Orifice Holder Assembly (5K) (Right Rear)	10	W10439242	Burner, Broiler		W11428858	Electrode (Right Front, Right Rear, Center)
	W11345012	Orifice Holder Assembly (8K) (Center)	11	W10680035	Burner, Bake	22	W10673618	Screw
3	W10295996	Bracket, Saddle Valve	12	W10720102	Valve, Gas	23	W10827923	Spring, Electrode
4	W10510125	Tubing, Main Supply	13	W10324262	Igniter, Bake			FOLLOWING PARTS NOT ILLUSTRATED
5	W10783317	Switch, 5 Burner Manifold Harness	14	W10306050	Tube, Broil Supply (Broiler Fitting To Valve)		W11415424	LP 5 Orifice Conversion Kit
6	3601P336-45	Baffle, Broil Burner	15	W10776437	Fitting, Broil		W10566535	LP Conversion Kit (Bake/Broil)
7	W11418925	Manifold Assembly	16	W10333842	Electrode, Broil			
			17	W11428754	Orifice (18K) (Left Front)			
				W10849720	Orifice (10K) (Left Rear)			
				W11428753	Orifice (15K) (Right Front)			
				W10849719	Orifice (5K) (Right Rear)			
				W11429345	Orifice (8K) (Center)			

DOOR PARTS




DOOR PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11379948	Glass Spacer
2	W11091878	Screw
3		Handle, Door
	W10834521	Stainless
4	W10826568	Liner, Door
5	W10031790	Screw
6	W11223202	Glass, Inner

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
7	W10541911	Bracket, Glass Upper Handle
8	W10885519	Hinge, Door (Active)
9		Glass Assembly, Outer Door
	W10867480	Stainless
10	W10675397	Scoop, Door

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
11	W10327235	Screw
12	W10813139	Rail, Vertical Support
13	W10031780	Screw
14	W10813140	Rail, Horizontal Support
15	W10612925	Badge
16	W10319024	Washer, Door

DRAWER PARTS



DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Panel, Drawer Front
	W10861565	Stainless
2	3196169	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
3	W10688022	Drawer, Storage

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4	W10441804	Slide, Drawer (Left)
	W10441805	Slide, Drawer (Right)
5	W10318026	Bracket, Mounting

OPTIONAL PARTS (NOT INCLUDED)

REFINISHING MATERIAL

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

INSULATION

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2" x 24" x 120")
	240132	Insulation (2-1/2" x 22" x 120")

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	511873	White Porcelain (2 oz.)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black
	206922	Primer (White)

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)