




## **UNDERCOUNTER DISHWASHER**

### **MODELS:**

JDPSG244LS0 (Stainless)

# DOOR AND PANEL PARTS




Literature Parts

# DOOR AND PANEL PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	5		Access Panel	10		Toe Panel
	W11323304	Owners Manual		W11108979	Black		W11108991	Black
	W11366144	Tech Sheet	6		Panel, Front (Includes Item 11)	11	W10692757	Barrel Nut, Front Panel
	W11428466	Energy Guide		W11465871	Stainless	12	W11438978	Screw, Black
2		Arm, Hinge	7	3400000	Screw	13	W10189731	Screw
	W10920232	Left Hand	8	W11364953	Screw	14	W10919859	Insulation, Front Panel
	W10920230	Right Hand	9	W11038694	Insulation, Single Layer	15	W10919858	Insulation, Multi-Layer
3	W11377160	Cross Brace, Door						
4	W10829406	Pocket, Handle						


# CONTROL PANEL AND INNER DOOR PARTS



# CONTROL PANEL AND INNER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Console Assembly	10	W11098822	Inner Door Assembly	18	W11397505	Fuse, In-line
	W11099344	Black	11	W11454757	Seal, Door Bottom	19	W11038734	Duct, Vent
2	W11084876	Jumper, Door	12	W11391581	Wiring Harness, Main (Includes Thermostat & Fuse)	20	W10348408	Screw
3	W11258418	Screw				21	W11448735	Jumper, Ground
4	W10711884	Screw (Long)	13	W11084867	Wiring Harness, Inner Door			
5	W11091934	Latch Assembly (Includes Switch)	14	W11092649	Dispenser Assembly			
6	W11445506	Control, Electronic	15	W11265187	Seal, Console/Door			
7	W11025634	Bezel, Vent (Also Order Gasket)	16	W11088985	Hanger, Control			
8	W11184028	Gasket, Vent	17	W11038720	Vent Assembly (Includes Fan)			
9	W10348409	Screw			(Also Order Gasket)			


# TUB AND FRAME PARTS



# TUB AND FRAME PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10920228	Tub Assembly (Includes Gasket)	13	W11255994	Float Switch	24	W11362500	Miscellaneous Parts Bag (Contains 2 Screws, 2 Clamps, & 2 Brackets)
2	W11226744	Base, Terminal Box	14	W11184083	Plug, Tub			
3	W11035860	Gasket, Tub	15	W11429970	Water Inlet Assembly	25	W11367646	Sound Insulation, Bottom
4	W11429974	Nut, Water Inlet	16	W11455395	Leg, Leveling	26	W11536143	Heater Element Assembly
5	W11090487	Strike, Latch	17	3378128	Washer, Pronged Cup	27	W11132441	Terminal Block Following Part Not Illustrated:
6	W11296374	Screw	18	3400014	Screw, Grounding			
7	W11165091	Seal, Cabinet	19	3400892	Screw			
8	W11025993	Drip Tray	20	W11226746	Cover, Terminal Box			
9	W11025986	Funnel, Overfill Protection	21		Side Support, Tub			
10	W11025988	Funnel Extension		W10920122	Left Hand		W11411561	Insulation Pack (Includes 2 side & 1 top piece)
11	8269145	Bracket, Undercounter		W10920120	Right Hand			
12	W11165093	Cover, Tub Corner	22	W11221921	Shiled, Tub Sound			
			23	W10919865	Insulation, U-Wrap			

# PUMP, WASHARM AND MOTOR PARTS






# PUMP, WASHARM AND MOTOR PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11048807	Pump Assembly	10	W11243648	Motor & Sump Assembly	20	370445	Clamp, Hose
2	W11034554	Sump with Seal (Includes 3, 4, 5, 6 & 9)	11	W11036660	Isolator, Rear Motor	21	W11163419	Bracket, Thermostat
3	W10891543	Diffuser, Inlet	12	W11250985	Hose, Pressure	22	W11193089	Thermostat (Included with Main Wiring Harness)
4	W11050773	Drain Vent Assembly	13	W10900389	Hose, Suction	23	W11025970	Fill Valve Assembly
5	9741232	Screw	14	W11193157	Motor, Drain	24	W11122851	Clamp, Hose
6	W10891547	Check Valve, Drain	15	W11131184	Hose, Drain	25	W11036159	Hose
7	W11048456	Wash Arm Assembly	16	W11175571	Disc, Diverter	26	W11036143	Clip, Hose
8	371505	Clamp, Hose	17	W11025961	Bracket, Rear Motor	27	W10466656	Clamp, Hose
9		Diverter Valve Motor (Not Serviced)	18	W11418271	Fastener	28	W11036287	Hose, Inlet
			19	W11126174	Indicator, Optical Wash	29	W11236576	Clamp, Hose


# UPPER WASH AND RINSE PARTS



# UPPER WASH AND RINSE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10903503	Feed Tube Assembly	5	W11128231	Cover, Diverter	7	W10891533	Filter
2	W11039888	Retainer	6	W10892836	Retainer, Docking (2nd Level)	8	W10891539	Screen
3	W11039869	Sprayarm, Third Level						
4	W11174340	Upper Sprayarm Assembly						


# UPPER RACK AND TRACK PARTS



# UPPER RACK AND TRACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10847873	Dishrack, Upper	6		Rack Adjuster	11	W11180176	Button, Adjuster Arm
2		Track, Assembly		W11180155	Left Hand	12	W11129799	Cupshelf Assembly
	W11212732	Left Hand		W11180153	Right Hand	13	W11129797	Clip, Cupshelf
	W11212734	Right Hand	7	W11189985	Tine Row, Fold Down	14	9741232	Screw
3	W11180605	Clip, Adjuster Arm	8	W11179755	Positioner	15	W11170270	Screw
4	W11268684	Handle, Dishrack	9	W11179753	Clip, Pivot			
5	W11373129	Handle, Dishrack Rear	10	W11180178	Leveler, Adjuster Arm			

# LOWER RACK PARTS



# LOWER RACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11129939	Dishrack, Lower	5	W11267718	Lid, Silverware Basket	10	W11373129	Handle, Dishrack Rear
2	W11133746	Wheel & Transport Assembly	6	W10610895	Tine Row, Sliding	11	W11267722	Knife Holder
3	W11281130	Silverware Basket Assembly	7	W11268684	Handle, Dishrack	12	9741232	Screw
4	W11268661	Retainer, Sliding Tine Row	8	W10056351	Tinerow			
			9	W11268658	Retainer, Flex Row			

# OPTIONAL PARTS (NOT INCLUDED)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
		DRAIN HOSE
W10712310		12 Ft.
		VINYL TOUCH-UP (4oz)
676453		White
676455		Grey
4396853		Silver Atlantis
		MOISTURE BARRIER KIT
4396277		Barrier Kit

## PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	4392899	Biscuit/Bisque
	4396603	Meteorite

## PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black
	4392901	Biscuit/Bisque

## PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)
	4392900	Biscuit/Bisque

## POWER CORD KIT

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	4317824	Power Cord Kit (Included Cord & Misc. Hardware)

## ANTI-TIP KIT

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	8171477	Floor Mount Kit
	8212560	Side Mount Kit

## DISHRACK REPAIR

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	4396838	White
	4396840	Grey
	4396854	Silver Atlantis