




UNDERCOUNTER DISHWASHER

MODELS:

WDT730HAMZ0 (Stainless)


DOOR AND PANEL PARTS



DOOR AND PANEL PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	5		Access Panel (Includes Hardware)	12		Handle Assembly
	W11528937	Energy Guide					W11439703	Stainless
	W11532445	Owners Manual		W10852733	Black	13	W10519755	Insulation, Toe Panel
	W11532444	Tech Sheet	6	W10884775	Badge	14	W10693137	Screw, Set
2		Arm, Hinge	7	8268961	Sleeve, Friction	15	W10316572	Screw
	W11484017	Left Hand	8	W10692757	Barrel Nut, Front Panel	16	W11049903	Stud, Mounting
	W11484018	Right Hand	9	W11504190	Light, Pipe	17	W10853886	U-nut
3	W10803537	Stiffener, Door	10	3400071	Screw	18	W10711884	Screw
4		Panel, Front (Includes 6, 8, 9, 15 & 16)	11	W10315897	Insulation, Front Panel	19	302868	Screw (Black)
	W11528197	Stainless						


CONTROL PANEL AND LATCH PARTS



CONTROL PANEL AND LATCH PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Console Assembly	2	W10825638	Box, Connector	5	W11096645	Screw
	W11589973	Black	3	W10825369	Brace, Connector	6	W10653840	Latch Assembly (Includes Switch)
			4	W11557320	Control, Electronic			


INNER DOOR PARTS



INNER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10348409	Screw	5	W11510782	Vent Assembly w/ Fan	9	W11515202	Wiring Harness
2	W11050927	Seal, Console/Door	6	W11476843	Screw	10	W11510780	Duct, Vent
3	W11521812	Inner Door Assembly	7	W11531479	Deflector, Vent	11	W11184028	Gasket, Vent
4	W10920683	Door Bottom, Seal	8	W10620296	Dispenser Assembly			


FILL, DRAIN AND OVERFILL PARTS



FILL, DRAIN AND OVERFILL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	370445	Clamp, Hose	6	371505	Clamp, Hose	10	304231	Screw
2	W10769066	Inlet Hose	7	W11130743	Fill Valve Assembly	11	W10195039	Switch, Overfill Control
3	W10195536	Inlet, Water (Also Order Item 4)	8	W10786175	Miscellaneous Parts Bag (Contains 2 Screws, 2 Clamps, & 2 Brackets)	12	W10316267	Standpipe, Overfill
4	8531323	Gasket				13	W10346525	Float & Retainer Assembly
5	W10508676	Nut, Inlet (Also Order Item 4)	9	W10545278	Drain loop with check valve assembly	14	W10195037	Lever, Overfill Switch


TUB AND FRAME PARTS



TUB AND FRAME PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11502321	Tub Assembly	15	3371618	Thermostat	23	W10277003	Screw
2	W11521240	Shield, Thermostat	16	W10544004	Strike, Latch	24		Tub Mount, Third Level Rack
3	W11425053	Seal, Tub	17	3378128	Washer, Pronged Cup		W11504623	Left Hand
4	W10341745	Screw	18	3400014	Screw, Grounding		W11504624	Right Hand
5	W11296374	Screw	19	W10819539	Sound Insulation, Bottom	25	W11364953	Screw
6	8269145	Bracket, Undercounter	20	8268990	Bushing, Door Spring	26	489470	Screw
7	W10304231	Support, Bottom	21	W10732961	Bracket, Heater Support			
8	W10619352	Leveler, Leg	22	W10441445	Heater Element Assembly			
9	W10337934	Spring, Door Balance			(Includes Heater Washer & Nut)			
10	W10902242	Wheel Assembly						
11	3400892	Screw						
12	8268991	Cover, Terminal Box						
13	W10866979	Shield, Tub Sound			NOTE: If heater element is removed, it must be replaced.			
14	W10539489	Clip, Thermostat						


PUMP, WASHARM AND MOTOR PARTS



PUMP, WASHARM AND MOTOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10455271	Cover, Outlet	8	W10724439	Pump, Drain	16	W10445975	Hose Assembly (Includes 2 Clamps)
2	W10455268	Sump With Seal (Also Order Items 12 & 16)	9	8269144	Hose, Drain	17	W10491331	Sprayarm
3	W10463906	Screen	10	370445	Clamp, Hose	18	W10910428	Motor, Diverter
4	W10348407	Screw	11	W11525024	Sensor, Temperature	19	9741232	Screw
5	W11525550	Sump & Motor Assembly	12	W11182008	Grommet	20	W10476221	Disc, Diverter
6	W10372113	Tab, Sump	13	8269146	Clamp, Hose			
7	W10789806	Filter Cup Assembly	14	W10195086	Motor, Isolator			
			15	W11521436	Motor (Also Order Items 12 & 16)			


UPPER WASH AND RINSE PARTS



UPPER WASH AND RINSE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11499881	Feed Tube Assembly (Includes Items 2 & 3)	2	W11504677	Sprayarm, Third Level	4	W11533287	Manifold
			3	W11039888	Retainer	5	W11533286	Sprayarm, Upper


UPPER RACK AND TRACK PARTS



UPPER RACK AND TRACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10847876	Dishrack, Upper	7	W11267702	Button, Adjuster Arm	11	W11509750	Clip, Adjuster Arm
2	W11186528	Tine Row, Fold Down	8		Rack Adjuster	12	3379676	Wheel
3	3385089	Track, Dishrack		W11503620	Left Hand			
4	W10082860	Stop, Track (Non-Removable)		W11503619	Right Hand			
5	W11179794	Positioner	9	W10508950	Stop, Track (Removable)			
6	W11179753	Clip, Pivot	10	W11180178	Leveler, Adjuster Arm			


LOWER RACK PARTS



LOWER RACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10525646	Dishrack, Lower	4	W10056272	Tine Row, Fold Down	6	W10179398	Silverware, Basket
2	W10082868	Wheel & Transport Assembly	5	W10078215	Retainer, Tine Row Combo	7	W10193647	Lid, Side
3	W11550304	Silverware Basket Assembly						

THIRD LEVEL RACK AND TRACK PARTS



THIRD LEVEL RACK AND TRACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11441109	Track, Dishrack	3	W11048219	Wheel	4	W11084874	Track Stop, Front
2	W11507404	Rack, Third Level				5	W11084872	Track Stop, Rear

OPTIONAL PARTS (NOT INCLUDED)

ACCESSORIES

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
		SIDE PANEL KITS
	8171656	White
	8171657	Black
	8171658	Biscuit/Bisque
	8171659	Stainless Steel
		MOISTURE BARRIER KIT
	4396277	Barrier Kit
		DRAIN HOSE
	3385556	12 Ft. Handle Assembly
	W10702080	Black
	W10702081	White

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	4392899	Biscuit/Bisque

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black
	4392901	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)
	4392900	Biscuit/Bisque

POWER CORD KIT

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	4317824	Power Cord Kit (Included Cord & Misc. Hardware)

ANTI-TIP KIT

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	8171477	Floor Mount Kit
	8212560	Side Mount Kit

DISHRACK REPAIR

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
		TINE TIP REPAIR KIT (Enough for Two Complete Racks)
	4396838	White
	4396840	Grey
	4396854	Silver Atlantis
		VINYL TOUCH-UP (4oz)
	676453	White
	676455	Grey
	4396853	Silver Atlantis