





**30" GAS FREESTANDING RANGE**

**MODELS:**

WFG505M0MS0 (Stainless)


# COOKTOP PARTS



# COOKTOP PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	9	98013389	Bumper, Cooktop	14	W10613666	Bracket, Anti-Tip
	W11508820	Instructions, Installation	10	98005000	Screw	15	7101P485-60	Screw, Anti-Tip Kit
	W11508721	Guide, Use and Care	11		Cap, Burner	16	W11357363	Oval Burner Assembly
	98007130	Tips, Safe Cooking (English)		W11448875	Black (Left Front & Right Front)			(Center)
	W11508879	Sheet, Tech		W11448464	Black (Left Rear)	17	98005658	Screw (Stainless)
2		Cooktop		W11453728	Black (Right Rear)	18	W10465081	Grate, Bumper
	W11443179	Black				19	8273062	Screw
3		Panel, Manifold	12	8534079	Screw, Ground			FOLLOWING PARTS NOT ILLUSTRATED
	W11578531	Black	13	W11352018	Spreader, Flame (Left Front & Right Front)	W11465032		Harness, Main
4		Knobs				98005896		Clip, Wire
	W11488096	Black				98015022		Bushing, Snap
5	98007225	Screw		W11352020	Spreader, Flame (Left Rear)	3391018		Tie, Cable
6		Set, Grate				W11492747		Insulation, Manifold
	W11465357	Black		W11352021	Spreader, Flame (Right Rear)			
7	98004722	Clip, Cooktop						
8	6610473	Wire, Ground						


# BACKGUARD PARTS



# BACKGUARD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap (Left Hand)	3	98006632	Screw	6	W10535746	Bracket, Console Mount
	W10873109	Black	4		Console, Assembly			
		Endcap (Right Hand)		W11488008	Stainless with Overlay	7	98008545	Screw (Black)
	W10873107	Black	5		Control, Electronic	8	W11462420	Bracket, Control
2	W10535808	Backguard, Rear		W11520704	Black	9	W10535815	Bracket, Rear
						10	W10493726	Screw


# MANIFOLD PARTS



# MANIFOLD PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	98007410	Bracket, Regulator	14	98005659	Screw	22	W10574737	Bracket, Valve
2	W11459683	Assembly, Tubing (Left Front)	15	W11509768	Valve, Saddle (Left Front & Right Front)	23	W10512963	Tubing (Regulator to Oven Valve)
	W11459686	Assembly, Tubing (Right Front)		W11509767	Valve, Saddle (Left Rear & Center)	24	W10669525	Electrode (Left Front, Right Front & Center)
3	W11495381	Assembly, Tubing (Center)		W11509766	Valve, Saddle (Right Rear)		W10876260	Electrode (Left Rear, Right Rear)
4	W11459685	Assembly, Tubing (Left Rear)	16	98017517	Screw	25	W10827923	Electrode, Spring (Left Front, Right Front, Left Rear, Right Rear & Center)
	W11459684	Assembly, Tubing (Right Rear)	17	W11509588	Assembly, Manifold			
5	W11281168	Spark Module	18	98013634	Screw			
6	98007225	Screw	19	W11466755	Regulator	26	W10673618	Screw
7	W10619922	Tube 3/8" Manifold To Reg	20	W11485872	Orifice (15K) (Left Front & Right Front)			FOLLOWING PARTS NOT ILLUSTRATED
8	W10670196	Spread, Flame (Bake)		W11498976	Orifice (8K) (Center)		W11517377	Kit, LP Conversion
9	98006726	Screw (Black)		W11548158	Orifice, Natural (9.5K) (Left Rear)			
10	W10650358	Oven Burner Asm-US Electronic		W11485871	Orifice (5K) (Right Rear)			
11	W10493726	Screw	21	W11208965	Igniter, Hot Surface			
12	W11542590	Harness, Switch						
13	W11449991	Valve, Oven						

# CHASSIS PARTS






# CHASSIS PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10675411	Box, Flue	11	W10620410	Assembly, Oven Bottom	25	W11510655	Clip, Tubing
2	W10554269	Socket - Oven Light	12	W10577312	Support, Side Panel	26	W11492823	Cover
3	W10636342	Shield, Insulation	13	W10670197	Deflector, Oven	27	W10788320	Bulb, Light
4		Panel, Side	14	W10520269	Rail, Base			FOLLOWING PARTS NOT ILLUSTRATED
	W10666212	Black (Left)	15	W10545322	Bracket, Manifold	W11130754	W11130754	Wrapper oven cavity insulation
	W10666211	Black (Right)	16	W11172758	Bracket, Foot	W11048974	W11048974	Insulation, Back
5	98005502	Clip, Oven Botton	17	W10549293	Safety Valve, Rear Cover	W10613818	W10613818	Insulation, Upper
6	W10902689	Counterweight	18	W10640762	Cord, Power	W11506534	W11506534	Insulation,Flue
7	98015363	Support, Rear	19	W10181986	Sensor, Oven	98004294	98004294	Wire Tie, Insulation
8	W10327222	Counter Support-Hinge	20	W10532560	Side Panel, Support			
9	W10650383	Foot Leveling & Foot Base	21	W10535778	Seal, Oven			
		(Front)	22	W10493726	Screw			
10	W10058460	Foot, Leveling (Rear)	23	W10550642	Rack, Oven			
			24	98008545	Screw (Black)			


# OVEN AND BROILER PARTS



# OVEN AND BROILER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11620318	Baffle, Base	8	98006726	Screw (Black)	14	98004052	Bumper, Door
2	W10119413	Screw	9	W10446851	Liner, Broiler Drawer	15	98004993	Screw
3	98008545	Screw (Black)	10	W10682676	Back Cover, Broiler			
4	W10155121	Screw	11	W10216478	Insulation, Broiler Door			
5	W10624273	Cover, Broiler Left	12		Panel, Broiler Door			
	W10624275	Cover, Broiler Right		W11451944	Stainless			
6	W10647966	Hinge	13	W11176979	Handle Broiler Door- Universal Silver			
7	W10605426	Panel, Side						

# DOOR PARTS



# DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	98005521	Screw (Stainless)	6	W10535788	Hinge, Oven Door	12	98004993	Screw
2	W10292266	Seal, Inner Door	7		Glass, Outer Door	13	W10146346	Screw
3	W10544145	Upper Trim, Oven Door		W11506543	Stainless	14	W10811550	Black
4		Trim, Side	8	W10675413	Cross Support	15	W11569276	Handle, Support Bracket
	W11184558	Left	9	W11528109	Glass, Inner			
	W11184560	Right	10		Handle, Oven Door			
5	W10884775	Badge		W11442150	Stainless			
			11	98008699	Screw			

# OPTIONAL PARTS (NOT INCLUDED)

## REFINISHING MATERIAL

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

## PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	511873	White Porcelain (2 oz.)

## PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

## INSULATION

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2" x 24" x 120")
	240132	Insulation (2-1/2" x 22" x 120")

## PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black

## MISCELLANEOUS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	98012220	Kit, Door Pin