




GAS COOKTOP

MODELS:

KCGS556ESS05 (Stainless)


COOKTOP, BURNER AND GRATE PARTS



COOKTOP, BURNER AND GRATE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	8	8286815	Head, Burner (Left Front and Right Front)	14	W10639175	Assembly, Burner Base (20K)
	W10672375	Instructions, Undercounter Install		8286813	Head, Burner (Left Rear)	15	W10657994	Electrode, Burner
	W11468901	Owner's Manual		8286814	Head, Burner (Right Rear)	16	W10416057	O-Ring
	W11466943	Quick Start Guide			Bezel	17	8286863	Spring, Electrode
2		Cooktop	9		Stainless			INSULATION PARTS NOT ILLUSTRATED
	W10722085	Stainless		W10593536	Stainless		W10617401	Insulation, Cooktop
3		Kit, Burner Cap	10	8286921	Screw, Burner Rail (M4)			FOLLOWING PARTS NOT ILLUSTRATED
	W10617345	Black	11	W10674732	Orifice (10K) (Left Front and Right Front)		W10889267	Harness, Main (Switch)
4		Grate Assembly (Includes Three Grates)			Orifice (Left Rear)		W10878749	Harness, Spark Module
	W11108271	Black		W10151353	Orifice (Left Rear)		3801F935-51	Bracket, Tie Down
5		Kit, Burner Cap		W10674728	Orifice (Right Rear)		7101P062-60	Screw (Used For Tie Down Bracket)
	W10635600	Black (Includes Melt Cap)	12	W11439331	Wiring, Electrode (Left Front and Right Front)		3400015	Screw, Grounding
6		Knobs, Cooktop			Wiring, Electrode (Left Rear and Right Rear)		W10392003	Cord, Power
	W10545849	Stainless		W11439332			W10132200	Relief, Strain
7	W10674920	Holder, Orifice (10K) (Left Front and Right Front)	13	W10808715	Spreader, Burner		7208P024-60	Seal, Manifold Pipe Inlet
	W10674918	Holder, Orifice (6K) (Left Rear)					W10676662	Kit, LP Conversion
	W10674919	Holder, Orifice (7K) (Right Rear)						

BURNER BOX, GAS VALVES AND SWITCH PARTS



BURNER BOX, GAS VALVES AND SWITCH PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10743274	Screw	8	W10594429	Bracket, Orifice Holder	16	W10545800	Tubing, Gas Burner
2	W10682073	Assembly, Pipe Manifold	9	W10475149	Module, Spark			(Center, Simmer)
3	W10717630	Valve, Single (Left Front and Right Front)	10	W10710917	Box, Burner	17	W11507167	Seal, Switch Shaft
	W10617357	Valve, Single (Left Rear)	11	W10545802	Bracket, Dual Burner	18	3196537	Screw
	W10717628	Valve, Single (Right Rear)	12	W10545796	Tubing, Gas Burner (Left Front and Right Front)			ACCESSORIES NOT INCLUDED OR ILLUSTRATED
	W10717629	Valve, Dual (Center)	13	W10545797	Tubing, Gas Burner (Left Rear)	W11042467		Spray, Stainless Steel Cleaning
4	8287055	Bracket, Single Valve	14	W10545798	Tubing, Gas Burner (Right Rear)			
5	8287056	Bracket, Dual Valve	15	W10545801	Tubing, Gas Burner (Center, Main)			
6	W10705475	Panel, Front						
7	W10449143	Regulator, Pressure						