


KitchenAid®

GAS COOKTOP

MODELS:

KCGS550ESS05 (Stainless)


COOKTOP, BURNER AND GRATE PARTS



COOKTOP, BURNER AND GRATE PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	8	8286815	Head, Burner (Left Front and Right Front)	15	W10657994	Electrode, Burner
	W10672375	Instructions, Undercounter Install				16	W10416057	O-Ring
	W11468901	Owner's Manual		8286813	Head, Burner (Left Rear)	17	8286863	Spring, Electrode
	W11466943	Quick Start Guide		8286814	Head, Burner (Right Rear)			INSULATION PARTS NOT ILLUSTRATED
2		Cooktop				W10617403		Insulation, Cooktop
	W10722084	Stainless	9		Bezel			FOLLOWING PARTS NOT ILLUSTRATED
3		Kit, Burner Cap		W10593536	Stainless			
	W10617345	Black	10	W10758282	Screw	W10889266		Harness, Main (Switch)
4		Grate Kit (Includes 3 Grates)	11	W10674732	Orifice (10K) (Left Front and Right Front)	W10878749		Harness, Spark Module
	W11108276	Black						
5		Kit, Burner Cap		W10151353	Orifice (Left Rear)	3801F935-51		Bracket, Tie Down
	W10635600	Black (Includes Melt Cap)		W10674728	Orifice (Right Rear)	7101P062-60		Screw (Used For Tie Down Bracket)
6		Knobs, Cooktop	12	W11439331	Wiring, Electrode (Left Front and Right Front)	3400015		Screw, Grounding
	W10545849	Stainless				W10392003		Cord, Power
7		Holder, Orifice (10K) (Left Front and Right Front)		W11439332	Wiring, Electrode (Left Rear and Right Rear)	W10132200		Relief, Strain
	W10674918	Holder, Orifice (6K) (Left Rear)				W10676662		Kit, LP Conversion
	W10674919	Holder, Orifice (7K) (Right Rear)	13	W10808715	Spreader, Burner	7208P024-60		Seal, Manifold Pipe Inlet
			14	W10625853	Assembly, Burner Base (17K)			

BURNER BOX, GAS VALVES AND SWITCH PARTS



BURNER BOX, GAS VALVES AND SWITCH PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10743274	Screw	8	W10594429	Bracket, Orifice Holder	16	W10545800	Tubing, Gas Burner
2	W10682072	Assembly, Pipe Manifold	9	W10475149	Module, Spark			(Center, Simmer)
3	W10717630	Valve, Single (Left Front and Right Front)	10	W10710916	Box, Burner	17	8286921	Screw, Burner Rail (M4)
	W10617357	Valve, Single (Left Rear)	11	W10545802	Bracket, Dual Burner	18	W11507167	Seal, Switch Shaft
	W10717628	Valve, Single (Right Rear)	12	W10545796	Tubing, Gas Burner (Left Front and Right Front)	19	3196537	Screw
	W10717629	Valve, Dual (Center)	13	W10545797	Tubing, Gas Burner (Left Rear)			ACCESSORIES NOT INCLUDED OR ILLUSTRATED
4	8287055	Bracket, Single Valve	14	W10545798	Tubing, Gas Burner (Right Rear)	W11042467		Spray, Stainless Steel Cleaning
5	8287056	Bracket, Dual Valve	15	W10545801	Tubing, Gas Burner (Center, Main)	W10662080		Griddle
6	W10705474	Panel, Front						
7	W10449143	Regulator, Pressure						