


KitchenAid®

GAS RANGE

MODELS:

KFGG500EWH7 (White)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	6		Panel, Manifold	16	W10465081	Grate, Bumper
	W11426598	Owners Manual		W10724448	White			FOLLOWING PARTS NOT ILLUSTRATED
	W11565451	Tech Sheet	7		Knob			
	W11427469	Quick Start Guide		W10786063	Stainless		W11461074	Harness, Main
2		Burner Cap Kit	8		Grate Kit		W10753750	Harness, Bake and Broil
	W11369523	Black (Set of 5)		W11241658	Black (Set of 2)			
3	W10067840	Screw	9	W11379946	Manifold Panel Bracket		W10334923	Clip, Gas Wiring
4	W11352018	Spreader, Flame (Left Front and Right Front)	10	W11379358	Rear Gas Cooktop Bracket		313438	Clip, Harness
	W11352020	Spreader, Flame (Left Rear and Center)	11	W10432544	Griddle		3196520	Clip, Wire
	W11352021	Spreader, Flame (Right Rear)	12	W11379945	Bracket, Anti-Tip		W10182767	Tie, Manifold Wire
		Cooktop	13	7101P485-60	Screw, Anti-Tip Kit		3196896	Clip, Wire
5		White	14		Bezel			
	W11418084			W10785119	Stainless (Kit of 5)			
			15	W10673618	Screw			


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap	6	W10192841	Shield, Heat	13	W10797001	Bracket, Ignitor
	W11130371	White (Left)	7	W11541195	Control (Maxwell)	14	3196169	Screw
	W11130378	White (Right)	8	W10762981	Bracket, Mounting	15	W10551614	Spreader, Clip-Spring
2	W10516123	Bracket, Console Mounting	9	W10184251	Cover, Back	16	3196165	Screw
3		Console Assembly	10	3196178	Screw			
	W10645847	White	11		Assembly, Active Overlay			
4	W10920631	Module, Spark DSI		W10645815	White			
5	W10198745	Cover, Upper	12	W10475149	Module, Spark			


CHASSIS PARTS



CHASSIS PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10314347	Assembly, Flue	18	W10323077	Diffuser, Flame	33	W10531060	Rack, Oven
2	9758701	Spacer, Door	19	3196178	Screw	34	W10289145	Rack, Oven (Gull-Wing)
3	W10273002	Bracket, Oven Support	20	W10919715	Gasket	35	W10501599	Clip, Front Frame Cover
4		Panel, Side	21	W11491752	Gasket, Door			
	W10575396	White	22	W10031780	Screw			
5	W10346153	Baffle, Full Convection	23	W10273195	Shield, Heat			FOLLOWING PARTS NOT ILLUSTRATED
6	W11511828	Switch, Door	24	W10273192	Rod, Door Switch			
7	W10137382	Clip, Panel	25	W10624590	Cord, Power		W10526208	Insulation, Wrap
8	W10341186	Front Foot Assembly	26	W10035900	Support, Oven Bottom		W10526209	Insulation, Main Back
9	W10289077	Receiver, Hinge	27	W11379356	Pan, Bake		4820F015-59	Insulation, Strap
10	W10058460	Foot, Leveling	28	W11544377	Light Assembly		3196896	Clip, Wire
11	W10211368	Bottom, Oven	29	W10571723	Bulb, Halogen 40 Watts			
12	W10586204	Sensor	30	W10390008	Base Rail Assembly (Left)			
13	3601P356-45	Baffle, Bake Burner		W10390007	Base Rail Assembly (Right)			
14	W10362924	Screw	31	W10874067	Motor, Fan (Convection)			
15	W10435470	Brace, Main Back	32	W10158780	Cover, Rear Fan			
16	W11040249	Assembly, Flue (Upper)						
17	3196560	Screw						


MANIFOLD PARTS



MANIFOLD PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10295997	Screw, Valve	9	W10224921	Bracket, Aegis	22	W10827923	Electrode, Spring
2	W11459263	Orifice Holder Assembly (18K) (Left Front)	10	W10439242	Burner, Broiler			FOLLOWING PARTS NOT ILLUSTRATED
	W11459258	Orifice Holder Assembly (9.5K) (Left Rear)	11	W10680035	Burner, Bake	W11489399		LP 5 Orifice Conversion Kit
	W11459260	Orifice Holder Assembly (15K) (Right Front)	12	W10720102	Valve, Gas	W10566535		LP Conversion Kit (Bake and Broil)
	W11459259	Orifice Holder Assembly (5K) (Right Rear)	13	W10324262	Igniter, Bake	W10465078		Orifice, LP Broil
	W11459261	Orifice Holder Assembly (8K) (Center)	14	W10306050	Tube, Broil Supply (Broiler Fitting To Valve)			
3	W10295996	Bracket, Saddle Valve	15	W10776437	Fitting, Broil			
4	W10510125	Tubing, Main Supply	16	W10333842	Electrode, Broil			
5	W10811693	Harness, Switch Spark	17	W11485988	Orifice (18K) (Left Front)			
6	3601P336-45	Baffle, Broil Burner		W11485873	Orifice (9.5K) (Left Rear)			
7	W11347746	Manifold Assembly		W11428753	Orifice (15K) (Right Front)			
8	W10566062	Valve, Gas (Left Front, Right Front)		W11485871	Orifice (5K) (Right Rear)			
	W10566057	Valve, Gas (Left Rear, Center)		W11485874	Orifice (8K) (Center)			
	W11331153	Valve, Gas (Right Rear)	18	W10362924	Screw			
			19	3196385	Screw			
			20	3400016	Screw			
			21	W11428831	Electrode (Left Front, Left Rear, Center)			
				W11428858	Electrode (Right Front and Right Rear)			

DOOR PARTS




DOOR PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Outer Door Glass Assembly
	W10495962	White
2	W10480830	Screw
3		Handle Assembly
	W10551000	Stainless
4	W10297318	Liner, Door
5	W10300487	Glass, Inner

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
6		Trim, Vent
	W10335331	White
7	W10327235	Screw
8	W10518672	Badge
9	W10440013	Hinge, Door (Active)
10		Side Trim, Door
	W10334003	White
11	W10294853	Bracket, Glass Liner

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
12	W10294851	Rail, Door
13		Trim, Bottom Door
	W10333990	White
14	W10772958	Insulation, Door
15	W10031780	Screw
16	W10031790	Screw
17	W10317886	Screw

DRAWER PARTS



DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Panel, Drawer Front
	W11449654	White
2	3196169	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
3	W10688022	Drawer, Storage

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4	W10441804	Slide, Drawer (Left)
	W10441805	Slide, Drawer (Right)
5	W10318026	Bracket, Mounting

OPTIONAL PARTS (NOT INCLUDED)

REFINISHING MATERIAL

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

INSULATION

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2 x 24 x 120 in)
	240132	Insulation (2-1/2 x 22 x 120 in)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	4392899	Biscuit and Bisque
	511873	White Porcelain (2 oz.)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	4392901	Biscuit and Bisque
	285006	Black
	350956	Almond
	350938	Gray Primer
	206922	Primer (White)

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

ACCESSORIES

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	W10355016	Cleaner, Stainless Steel
	W10355051	Cleaner, Cooktop
	W10423113RPKit	Oven Cleaning
	W10432019	Alt Cleaning Kit
	W10205524	Split Oven Rack
	4396923	Broiler Pan and Grid
	W10123240	Rack, Broiler Pan and Roasting