




30" GAS FREESTANDING SELF CLEAN RANGE

MODELS:

WFG525S0JS0 (Stainless)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	5		Panel, Manifold	15	W10673618	Screw
	W11333091	Instructions, Installation		W11050776	Stainless			FOLLOWING PARTS NOT ILLUSTRATED
	W11333082	Guide, Use and Care	6		Knob, Control		W10842520	Harness, Main
	W11333114	Sheet, Tech		W11023139	Stainless		W10753750	Harness, Bake/Broil
	W11351206	Diagram, Wiring	7		Kit, Grate		W10809927	Harness, Cooktop
2		Kit, Burner Cap		W11090908	Black		3196520	Clip, Wire
	W10183375	Black	8	3400701	Screw		W10334923	Clip, Gas Wiring
3	W10515455	Assembly, Burner (17.5K)	9	3196557	Screw		313438	Clip, Harness
		(Left Front & Right Front)	10	W10306542	Bracket, Anti-Tip		3196896	Clip, Wire
	W10515454	Assembly, Burner (9.5K)	11	7101P485-60	Screw, Anti-Tip Kit		3196173	Screw (Grounding)
		(Left Rear & Center)	12	W11194809	Electrode (Left Front, Left Rear, Right Front)			
	W10515453	Assembly, Burner (6K)			(Center)			
		(Right Rear)		W10515459	Electrode (Right Rear)			
4		Cooktop	13	8273062	Screw			
	W10884167	Black	14	W10298664	Spreader, Flame			


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap	5	W10920631	Module, Spark DSI	11	3196169	Screw
	W11130372	Black (Left)	6	W10516123	Bracket, Console Mounting	12		Control, Electronic (LCX)
	W11130379	Black (Right)					W11204525	Black
2	8053505	Shield, Heat	7	8523412	Bracket, Rear Cooktop	13	3196178	Screw
3		Panel, Control	8	W10198745	Cover, Upper	14	W10695491	Bracket, Control
	W10835288	Stainless	9	W10192841	Shield, Heat	15	W10797001	Bracket, Ignitor
4	W10762981	Bracket, Mounting	10	W10184370	Cover, Back	16	W10475149	Module, Spark (5+0)


MANIFOLD PARTS



MANIFOLD PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10295997	Screw, Valve	7	W10859728	Assembly, Manifold	19	W10347414	Orifice (15K) (Left Front & Right Front)
2	W10295996	Bracket, Saddle Valve	8	W10279615	Valve, Gas (Left Front & Right Front)		W10170508	Orifice, Natural (9.5K) (Left Rear)
3	W10473936	Assembly, Orifice Holder (15K) (Left Front)		W10279614	Valve, Gas (Left Rear)		W10170506	Orifice, Natural (5K) (Right Rear)
	W10473932	Assembly, Orifice Holder (9.5K) (Left Rear)		W10247744	Valve, Gas (Right Rear)		W10657947	Orifice (8K) (Center)
	W10474166	Assembly, Orifice Holder (15K) (Right Front)		W10850894	Valve, Gas (Center)	20	W10137062	Spreader, Flame (Broiler)
	W10474162	Assembly, Orifice Holder (5K) (Right Rear)	9	W10224921	Bracket, Aegis	21	3196265	Screw
	W10836764	Assembly, Orifice Holder (8K) (Center)	10	3196385	Screw	22	W10362924	Screw
4	W10215439	Tubing (Manifold to Regulator)	11	3400016	Screw			FOLLOWING PARTS NOT ILLUSTRATED
5	W10811691	Harness, Igniter (Includes Switches)	12	8054078	Burner, Broiler		W11087531	Kit, LP 5 Orifice Conversion
6	9758079	Electrode, Bake	13	W10184491	Spreader, Flame (Oven)		W10566537	Kit, LP Bake and Broil
			14	9758078	Burner, Bake		W10400495	Orifice, LP Bake
			15	W10602001	Regulator		W10465080	Orifice, LP Broil
			16	W10333842	Electrode, Broil			
			17	W10420040	Tube, Broiler Supply			
			18	W10592836	Fitting, Broiler			


CHASSIS PARTS



CHASSIS PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10153186	Box, Flue	15	8053968	Shield, Lower	26	W10289077	Receiver, Hinge
2	8272747	Shield, Flue	16	W10390008	Assembly, Base Rail (Left)	27	W10627802	Switch, Door
3	8273036	Box-Burner, Gas Sealed		W10390007	Assembly, Base Rail (Right)	28	W11175594	Assembly, Light
4		Panel, Side				29	W10571723	Bulb, Halogen 40 Watts
	W10162245	Black	17	9757239	Rod, Door Switch	30	9761013	Assembly, Door Latch (Front)
5	W10137382	Clip, Panel	18	W10031780	Screw			
6	8523249	Bracket, Manifold	19	3400080	Screw	31	W10078370	Rod, Push Latch
7	W10362924	Screw	20	W10268578	Rack, Oven	32	W10107820	Assembly, Door Latch (Rear)
8	3196560	Screw	21	W10658354	Seal, Door			
9	W10341186	Assembly, Front Foot	22	W10435470	Brace, Main Back	33	W10674705	Glide, Drawer Front
10	W10058460	Foot, Leveling	23	9761449	Retainer, Insulation (Left)	34	3196178	Screw
11	3195097	Bottom, Oven		9761448	Retainer, Insulation (Right)			FOLLOWING PARTS NOT ILLUSTRATED
12	W10586204	Sensor					8524099	Insulation, Wrap
13	8053967	Baffle, Burner Oven	24	3196560	Screw		W10180437	Insulation, Back
14	8053969	Shield, Heat	25	W10624590	Cord, Power			


DOOR PARTS



DOOR PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Trim, Top (Includes Standoff)	10	W10299224	Hinge, Active (With Spring)	18		Trim, Lower Door
	W11241393	Stainless	11		Glass, Outer Door	8523177		Black
2	W10480830	Screw		W10884159	Black			
3		Handle, Door	12		Trim, Door			
	W11249084	Stainless		W10746436	Black (Left)			
4	9761344	Liner, Door		W10746435	Black (Right)			
5	W10031790	Screw	13	W10327235	Screw			
6	W11044424	Glass, Inner	14	W10544179	Strap, Door			
7	W10316950	Frame, Glass	15	W10299227	Hinge, Door (Passive)			
8	W10278991	Insulation, Door Strip	16	W10884775	Nameplate			
9	9761357	Retainer, Insulation	17	W10200660	Screw			

DRAWER PARTS



DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Panel, Drawer Front	2	W10688022	Drawer, Storage	4	3196169	Screw
	W11190207	Stainless	3	W10462909	Bracket, Mounting	5	W10674708	Glide, Drawer Rear

OPTIONAL PARTS (NOT INCLUDED)

REFINISHING MATERIAL

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

INSULATION

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2" x 24" x 120")
	240132	Insulation (2-1/2" x 22" x 120")

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	4392899	Biscuit/Bisque
	511873	White Porcelain (2 oz.)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

ACCESSORY PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	W10355016	Cleaner, Stainless Steel
	W10355049	Wipes, Stainless Steel Cleaning
	W10275756	Cleaner, Granite
	31617A	Cleaner, Grate & Drip Pan
	4396096RB	Griddle
	4396923	Grid, Broiler Pan and
	W10123240	Rack, Broiler Pan & Roasting
	4396927	Rack, Oven (Split)