THE SUBZERO

SABBATH GUIDE

HOW TO ENTER/EXIT SABBATH MODE

SUB-ZERO®



BUILT-IN COLUMN

TO SET SABBATH

1. While unit is on, touch POWER located on control panel
2. “OFF” Will appear on display
3. Touch and hold POWER for 10 seconds
4. “SAb” will appear in display

TO EXIT SABBATH MODE

1. Touch POWER

These appliances are certified by Star-K to meet strict religious regulations in conjunction with specific instructions found on www.star-k.org

BUILT-IN FRENCH DOOR

TO SET SABBATH

1. While unit is on, touch POWER located on control panel
2. “OFF” Will appear on display
3. Touch and hold POWER for 10 seconds
4. “SAb” will appear in display

TO EXIT SABBATH MODE

1. Touch POWER

These appliances are certified by Star-K to meet strict religious regulations in conjunction with specific instructions found on www.star-k.org

BUILT-IN OVER-AND-UNDER

TO SET SABBATH

1. While unit is on, touch POWER located on control panel
2. “OFF” Will appear on display
3. Touch and hold POWER for 10 seconds
4. “SAb” will appear in display

TO EXIT SABBATH MODE

1. Touch POWER

These appliances are certified by Star-K to meet strict religious regulations in conjunction with specific instructions found on www.star-k.org

BUILT-IN SIDE-BY-SIDE

TO SET SABBATH

1. While unit is on, touch POWER located on control panel
2. “OFF” Will appear on display
3. Touch and hold POWER for 10 seconds
4. “SAb” will appear in display

TO EXIT SABBATH MODE

1. Touch POWER

These appliances are certified by Star-K to meet strict religious regulations in conjunction with specific instructions found on www.star-k.org

BUILT-IN WINE STORAGE

TO SET SABBATH

1. While unit is on, touch POWER located on control panel
2. “OFF” Will appear on display
3. Touch and hold POWER for 10 seconds
4. “SAb” will appear in display

TO EXIT SABBATH MODE

1. Touch POWER

These appliances are certified by Star-K to meet strict religious regulations in conjunction with specific instructions found on www.star-k.org

COMPACT REFRIDGERATION

TO SET SABBATH

1. While unit is on, touch POWER located on control panel
2. “OFF” Will appear on display
3. Touch and hold POWER for 10 seconds
4. Unit will turn on and lights will be disabled

TO EXIT SABBATH MODE

1. Touch POWER

Note: Sabbath mode available on all undercounter models EXCEPT icemakers

These appliances are certified by Star-K to meet strict religious regulations in conjunction with specific instructions found on www.star-k.org

INTEGRATED COLUMN

TO SET SABBATH

1. On the interactive panel touch ▶ to enter the options screen
2. Touch ⚙ to enter the settings screen
3. Touch ★ to enter Sabbath option screen
4. Press and hold screen for 10 seconds to enter Sabbath mode

TO EXIT SABBATH MODE

1. Press and hold screen for 5 seconds to exit Sabbath mode

These appliances are certified by Star-K to meet strict religious regulations in conjunction with specific instructions found on www.star-k.org

INTEGRATED OVER-AND-UNDER

TO SET SABBATH

1. On the interactive panel touch ▶ to enter the options screen
2. Touch ⚙ to enter the settings screen
3. Touch ✡ to enter Sabbath option screen
4. Press and hold screen for 10 seconds to enter Sabbath mode

TO EXIT SABBATH MODE

1. Press and hold screen for 5 seconds to exit Sabbath mode

These appliances are certified by Star-K to meet strict religious regulations in conjunction with specific instructions found on www.star-k.org

INTEGRATED WINE STORAGE

TO SET SABBATH

1. On the interactive panel touch ▶ to enter the options screen
2. Touch ⚙ to enter the settings screen
3. Touch ☆ to enter Sabbath option screen
4. Press and hold screen for 10 seconds to enter Sabbath mode

TO EXIT SABBATH MODE

1. Press and hold screen for 5 seconds to exit Sabbath mode

These appliances are certified by Star-K to meet strict religious regulations in conjunction with specific instructions found on www.star-k.org

UNDERCOUNTER DRAWERS

TO SET SABBATH

1. On the interactive panel touch ▶ to enter the options screen
2. Touch ⚙ to enter the settings screen
3. Touch ★ to enter Sabbath option screen
4. Press and hold screen for 10 seconds to enter Sabbath mode

TO EXIT SABBATH MODE

1. Press and hold screen for 5 seconds to exit Sabbath mode

These appliances are certified by Star-K to meet strict religious regulations in conjunction with specific instructions found on www.star-k.org

PRO 48

TO SET SABBATH

1. While unit is on, touch POWER located on control panel
2. “OFF” Will appear on external display
3. Touch and hold POWER for 10 seconds
4. Unit will chime four times
5. Unit will power on disable external displays, lights, ice maker and door alarm.

TO EXIT SABBATH MODE

1. Touch POWER twice

These appliances are certified by Star-K to meet strict religious regulations in conjunction with specific instructions found on www.star-k.org

SUBZERO-WOLF.COM | 170116