

NO.	NAME	ITEM NO.	QTY
178	THERMOSTAT VALVE KNOB-30	6201831212	1
179	GRIDDLE THERMOSTAT VALVE KNOB-48	6201831211	2
180	LED LAMP SWITCH	6201831074	3
181	INDICATOR LIGHT	6201831039	3
182	AK SWITCH	6201831186	3
183	CONTROL PANEL	6302210190	1
184	OVEN THERMOSTAT VALVE	6201831040	1
185	GRIDDLE THERMOSTAT VALVE	6201831206	2
186	LED LAMP (WHITE)	6201831524	9
187	CONTROL PANEL SUPPORT	6302210191	1
188	MANIFOLD-FRONT-48	6201831204	1
189	MANIFOLD FIXED PIECE	6302210063	6
190	MAIN GAS VALVE FIXED SCREW	6201831091	12
191	MAIN GAS VALVE-18000	6201831130	3
177	MAIN GAS VALVE-9000	6201831029	3
192	STARMER MAIN GAS VALVE ALUMINUM GAS PIPE A	6201831245	3
193	MAIN GAS VALVE ALUMINUM GAS PIPE A	6201831239	3
194	STARMER MAIN GAS VALVE ALUMINUM GAS PIPE B	6201831246	3
195	MAIN GAS VALVE ALUMINUM GAS PIPE B	6201831240	3
196	HINGE-LEFT-30、48	6201831193	1
197	HINGE-RIGHT-30、48	6201831194	1
198	LED SWITCH-PRO	6201831074	1
199	LED LAMP-AK (WHITE)	6201831524	9

NO.	NAME	ITEM NO.	QTY
172	STRAIGHT BURNER BYPASS	6201831198/6201831199	1
171	U SHAPE BURNER BYPASS SUPPORT	6302210002	2
170	U SHAPE BURNER BYPASS	6201831027/6201831028	1
169	5/8" FLEX GAS LINE A	6201831052	1
168	U SHAPE BURNER BYPASS HEAT INSULATING COVER	6302210093	1
167	SUPPORT LEG-DOWN	6302210238	6
166	SUPPORT LEG-UP	6302210236	6
165	SAFETY VALVE BRACKET B	6302210009	2
164	BOTTOM PANEL	6302210160	1
163	SUPPORT LEG NUT	6201831008	6
162	BOTTOM PANEL STRENGTHENING RID	6302210161	2
161	BOTTOM PANEL HEAT PRESERVATION -B	6201831222	1
160	BOTTOM PANEL HEAT PRESERVATION -A	6201831221	1
159	5/8" FLEX GAS LINEF/J	6201831035/6201831204	2
158	U SHAPE BURNER SUPPORT-BOTTOM	6302210091	1
157	INNER BOTTOM PANEL	6302210162	1
156	U SHAPE BURNER FLAME TAMER-RIGHT	6302210005	1
155	U SHAPE BURNER	6201831026	1
154	U SHAPE BURNER FLAME TAMER-LEFT	6302210006	1
153	INNER BOTTOM PANEL-18''	6302210163	1
152	STRAIGHT BURNER SUPPORT	6302210234	1
151	STRAIGHT BURNER	6201831197	1
150	INNER BOTTOM PANEL FIXED PIECE	6302210017	4
149	U SHAPE BURNER SIDE PANEL-RIGHT	6302210004	1
148	RIGHT SIDE PANEL	6302210114	1
147	SIDE PANEL INNER-RIGHT	6302210115	1
146	BACK PANEL	6302210168	1
145	BACK PANEL STRENGTHENING RID	6302210170	1
144	BACK BAFFLE-DOWN	6302210169	1
143	REGULATOR-48	6201831203	1
142	MANIFOLD-BACK-48	6201831205	1
141	REGULATOR PROTECTION COVER-48	6302210165	1
140	3/4" FLEX GAS LINE	6201831056	1
139	5/8" FLEX GAS LINE K	6201831207	2
138	SAFETY VALVE	6201831031	4
137	SAFETY VALVE CONNECTOR	6201831032	8
136	5/8" FLEX GAS LINE G	6201831209	1
135	OVEN BROIL BURNER BYPASS	6201831024/6201831025	1
134	5/8" FLEX GAS LINE H	6201831210	1
133	BROIL BURNER JET HOLDER	6201831022	4
132	BROIL BURNER JET HOLDER NUT	6201831023	4
131	GRIDDLE BROIL BURNER BYPASS	6201831201/6201831202	1
130	LED LAMP TRANSFOMER	6201831077	1
129	POWER CORD	6201831071	1
128	POWER BOX COVER	6302210018	1
127	POWER BOX B	6302210019	1
126	RELAY	6201831043	1
125	SAFETY VALVE BRACKET A-48	6302210159	1
124	BROIL BURNER COVER-BACK	6302210033	1
123	BROIL BURNER SILICONE SPACER	6201831065	1
122	POWER BOX SUPPORT	6302210020	1
121	SUCTION OPENING A	6302210010	3
120	SUCTION OPENING B	6302210011	3
119	INNER PANEL-BACK	6302210171	1
118	CONVECTION FAN	6201831041	1
117	OVEN HEAT PRESERVATION COTTON-CENTIRE 48''	6201831235	1
116	OVEN BACK PANEL HEAT PRESERVATION COTTON-48	6201831228	1
115	REGULATOR PROTECTION COVER-BACK	6302210165	1
114	OVEN BACK PANEL HEAT PRESERVATION COTTON -48	6201831227	1
113	CONVECTION FAN SUPPORT A	6302210027	1
112	CONVECTION FAN HEAT PRESERVATION COTTON	6201831108	1
111	OVEN BACK PANEL	6302210184	1
110	U SHAPE BURNER SUPPORT	6302210007	1
109	REGULATOR INNER BAFFLE	6302210023	1
108	CONVECTION FAN COVER	6302210167	1
107	BACK SPLASH BACK PANEL	6302210173	1
106	BACK SPLASH	6302210172	1
105	BACK SPLASH FIXED PIN	6201831088	2
104	GRIDDLE COVER HANDLE	6201831219	1
103	GRIDDLE COVER	6302210203	1
102	IRON COOKING GRATE-48	6201831217	3
101	AK BURNER TOP CAP 18000	6201831112	3
100	AK NUT	6201831115	6
99	AK BURNER 18000	6201831113	3
98	AK BURNER IGNITER WIRE	6201831129	6
97	AK BURNER BASE 18000	6201831114	3
96	GRIDDLE STATOR-BACK	6302210216	1
95	GRIDDLE THERMOSTAT BRACKET	6302210217	3
94	GRIDDLE	6302210205	1
93	GREASE BOX	6302210204	1
92	DRIP PAN TRIM STRIP	6302210196	1
91	DRIP PAN A	6302210106	3
90	GRIDDLE BROIL BURNER BRACKET	6302210202	1
89	GRIDDLE BROIL BURNER	6201831200	1
88	U SHAPE BURNER HOT SURFACE IGNITER	6201831035	3

NO.	NAME	ITEM NO.	QTY
85	GRIDDLE BASE HEAT INSULATING PANEL	6302210200	1
84	DRIP PAN SUPPORT BEAM-BACK	6302210194	1
83	BURNER JET HOLDER SUPPORT	6302210104	1
82	GRIDDLE BASE SUPPORT BEAM	6302210215	1
81	AK BURNER BASE	6201831123	1
80	AK BURNER 9000	6201831122	1
79	AK BURNER TOP CAP 9000	6201831121	1
78	DRIP PAN SUPPORT BEAM B-FRONT	6302210105	1
77	AK JET HOLDER 9000	6201831124	1
76	AK JET HOLDER 18000	6201831116	1
75	DRIP PAN SUPPORT BEAM-FRONT	6302210195	1
74	SINGLE IGNITER	6201831085	1
73	CART BEAM SUPPORT-FRONT	6302210193	1
72	TOP INNER PANEL	6302210166	1
71	OVEN TOP PANEL HEAT PRESERVATION COTTON B-48	6201831230	1
70	BROIL BURNER COVER	6302210051	1
69	BROIL BURNER HEAT PRESERVATION COTTON	6201831107	1
68	BROIL BURNER	6201831021	1
67	OVEN TOP PANEL HEAT PRESERVATION COTTON A-48	6201831229	1
66	OVEN TOP PANEL	6302210183	1
65	THERMOSTAT BRACKET	6302210029	1
64	18''OVEN TOP PANEL	6302210183	1
63	18''OVEN BAFFLE	6302210175	1
62	OVEN BAFFLE	6302210174	1
61	BROIL BURNER WIRE SADDLE	6201831094	1
60	BROIL BURNER WIRE SADDLE PIECE	6302210032	1
59	OVEN HOT SURFACE IGNITER BRACKET	6302210031	1
58	OVEN HOT SURFACE IGNITER	6201831036	1
57	BROIL BURNER,DEPRESSION BAR	6302210052	1
56	BROIL PAN COVER	6302210123	1
55	BROIL PAN	6302210122	1
54	OVEN RACK-18	6201831216	1
53	OVEN RACK-30	6201831215	1
52	SUCTION OPENING SUPPORT	6302210013	1
51	FLUE BAFFLE	6302210120	1
50	OVEN LAMP	6201831042	1
49	BACK PANEL-18''	6302210185	1
48	OVEN PANEL HEAT PRESERVATION COTTON-CENTIRE	6201831235	1
47	BOTTOM PANEL HEAT PRESERVATION COTTON-CENTIRE	6201831225	1
46	INNER SIDE PANEL-RIGHT	6302210188	1
45	SIDE PANEL-LEFT	6302210116	1
44	INNER SIDE PANEL-LEFT	6302210231	1
43	HEAT PRESERVATION COTTON -LEFT&RIGHT OUTER PANEL	6201831098	1
42	HEAT PRESERVATION COTTON -LEFT&RIGHT UP INNER PANEL	6201831226	1
41	HEAT PRESERVATION COTTON -LEFT&RIGHT DOWN INNER PANEL	6201831102	1
40	OVEN INNER PANEL,LEFT	6302210189	1
39	U SHAPE BURNER SIDE PANEL, LEFT	6302210003	1
38			
37	SLIDE RACK	6201831157	1
35	FLAME TAMER	6302210229	1
34	BOTTOM PANEL COVER	6302210180	1
33	BOTTOM PANEL COVER-18''	6302210181	1
32	FLAME TAMER-18''	6302210230	1
31	BOTTOM PANEL-18''	6301210177	1
30	BOTTOM PANEL	6301210176	1
29	MIDDLE PANEL,BOTTOM	6302210158	1
28	OVEN FRAME-30''	6302210225	1
27	RECIEVER	6201831006	1
26	DOOR FRAME REINFORCED PIECE	6302210081	1
25	OVEN FRAME-18''	6302210226	1
24	DOOR GRASKET-30''	6201831187	1
23	DOOR GRASKET-18''	6201831188	1
22	DOOR FRAME INNER B-30''	6302210223	1
21	DOOR FRAME INNER B-18''	6302210224	1
20	WHITE GLASS-30''		
19	WHITE GLASS-18''		
18	DOOR HINGE RIGHT-18''	6201831196	1
17	DOOR HINGE LEFT-18''	6201831197	1
16	DOOR HEAT PRESERVATION COTTON B	6201831111	1
15	DOOR HEAT PRESERVATION COTTON B	6201831232	1
14	HEAT PRESERVATION COTTON B-48	6201831234	1
13	HEAT PRESERVATION COTTON A	6201831231	1
12	HEAT PRESERVATION COTTON A-48	6201831233	1
11	DOOR FRAME INNER	6302210220	1
10	DOOR FRAME INNER-18''	6302210221	1
9	GRAY CLASS-30''	6201831185	1
8	GRAY GLASS-18''	6201831190	1
7	30''DOOR FRAME OUTER	6302210227	1
6	18''DOOR FRAME OUTER	6302210228	1
5	18''DOOR HANDLE	6302210219	1
4	DOOR HANDLE	6302210218	1
3	DOOR HANDLE BASE	6201831148	1
2	NXR LOGO	6201831147	1
1	KICK PANEL	6302210222	1

未注公差	
>0.5~6	±0.25
>6~30	±0.45
>30~50	
>50~80	±0.60
>80~120	
>120~315	
>315	±1.00
角度	±0.5°

设计	邹国锋	日期 2018.12.12
核对		日期
审核		日期
批准		日期

标记	变更内容	日期	更 改	审核
A3				
A2				
A1				

宁波樱奇厨具有限公司

产品型号	NXRAK4807	产品类型	
零件名称	爆炸图		
图 号		物料编码	版 本
材 料			A0
零件数量	图 幅 A3	比 例	

0 9 8 7 6 5 4 3 2 1