Whirlpool®

30" INDUCTION COOKTOP

MODELS:

WCI55US0JS00 (Stainless)

COOKTOP PARTS

1

Literature Parts

3

5

4

2

9

7

6

8

COOKTOP PARTS

Illus. No.	Part No.	Description
1		Literature Parts
	W11362912	Installation Instructions
	W11245478	Instructions, Undercounter Installation
	W11362923	Owner's Manual
	W11362962	Tech Sheet
	W11362960	Wiring Diagram

Illus. No.	Part No.	Description
2	W11266244	Cooktop, Glass (Includes Stainless Trim)
3	W11279477	Spring, Cooktop
4	W11279478	Bracket, Cooktop Support
5	W11302457	Filter Support
6	W11209667	Element (10 inch) (Left Front)

Illus. No.	Part No.	Description
7	W11209662	Element (6 inch) (Left Rear & Right Rear)
8	W11209665	Element (8 inch) (Right Front)
9	W11325432	HMI Board

INTERIOR PARTS

INTERIOR PARTS

Illus. No.	Part No.	Description
1	W11431959	Module Assembly
2	W11246545	Blower Assembly
3	W11430778	Power Board (Ascari)

Illus. No.	Part No.	Description
4	W11430795	Power Board (Farina)

Illus. No.	Part No.	Description
5	W11249830	Communication Harness (IPC1 - IPC2)
6	W11347982	Jumper Harness (HMI to IPC)

OPTIONAL PARTS (NOT INCLUDED)

Illus. No.	Part No.	Description
		FOLLOWING PARTS NOT ILLUSTRATED
	W10328499	Kit, Mounting Marble Countertop
	W10310006	Adhesive, Marble Countertop
	8286642	Tape, Foam
		ACCESSORIES
	W11463464	Pot, Boiling
	W11463466	Pan, Frying
	W10355051	Cleaner, Cooktop
	WA906B	Scraper, Cooktop
	31463	Protectant, Cooktop
	W10355016	Cleaner, Stainless Steel