



**BROILER OVEN AND AUTOMATIC TOASTER
INSTRUCTION MANUAL
TOSTADORA/ASADORA
MANUAL DE INSTRUCCIONES**

**MODEL NUMBERS/ NUMERO DE MODELOS:
DT500/DT501B/DT502SS**

CAUTION:

BEFORE USE, PLEASE READ AND FOLLOW ALL SAFETY RULES AND OPERATING INSTRUCTIONS.

La sección en español empieza en la página 13.

Avanti has a policy of continuous improvement on its products and reserves the right to change materials and specifications without notice.

**Avanti Products, A Division of The Mackle Co., Inc.
P.O. Box 520604 - Miami, Florida 33152
www.avantiproducts.com**

Registration Information

Thank you for purchasing this fine Avanti product. Please fill out this card and return it within 100 days of purchase and receive these important benefits:

✍ **Protect your product:**

We will keep the model number and date of purchase of your new Avanti product on file to help you refer to this information in the event of an insurance claim such as fire or theft.

✍ **Promote better products:**


We value your input. Your responses will help us develop products designed to best meet your future needs.

------(detach here)-----

Avanti Registration Card

Name	Model #	Serial #
Address	Date Purchased	Store/Dealer Name
City State Zip	Occupation	
Area Code Phone Number	<u>As Your Primary Residence, Do You:</u> <input type="checkbox"/> Own <input type="checkbox"/> Rent	
<u>Did You Purchase An Additional Warranty:</u> <input type="checkbox"/> Extended <input type="checkbox"/> None	<u>Your Age:</u> <input type="checkbox"/> under 18 <input type="checkbox"/> 18-25 <input type="checkbox"/> 26-30 <input type="checkbox"/> 31-35 <input type="checkbox"/> 36-50 <input type="checkbox"/> over 50	
<u>Reason For Choosing This Avanti Product:</u> Please indicate the most important factors that influenced your decision to purchase this product. <input type="checkbox"/> Price <input type="checkbox"/> Product Features <input type="checkbox"/> Avanti Reputation <input type="checkbox"/> Product Quality <input type="checkbox"/> Salesperson Recommendation <input type="checkbox"/> Friend/Relative Recommendation <input type="checkbox"/> Warranty <input type="checkbox"/> Other _____	<u>Marital Status:</u> <input type="checkbox"/> Married <input type="checkbox"/> Single <u>Is This Product Used In The:</u> <input type="checkbox"/> Home <input type="checkbox"/> Business <u>How Did You Learn About This Product:</u> <input type="checkbox"/> Advertising <input type="checkbox"/> In Store Demo <input type="checkbox"/> Personal Demo <input type="checkbox"/> Other _____ Comments _____ _____ _____	

PARTS AND FEATURES



- | | |
|--|--|
| DOOR HANDLE | 8. BROWNING CONTROL SETTINGS |
| 2. OVEN WIRE RACK | 9. RESET BUTTON (STOP) *FOR TOASTER LEVER ONLY |
| 3. DRIP PAN | 10. TOASTER LEVER |
| 4. VIEWING WINDOW | 11. PULL OUT TOASTER CRUMB TRAY (REAR) |
| 5. OVEN CRUMB TRAY (UNDERNEATH) | 12. WIDE TOASTER SLOTS |
| 6. OVEN POWER ON INDICATOR | 13. TEMPERATURE CONTROL SELECTOR KNOB |
| 7. TIMER CONTROL KNOB WITH BELL SIGNAL | |

SETTING

Warm
Bake
Broil
Toast

TEMPERATURE

up to 150°F
between 250°- 450°F
over 450°F
at 450°F/Toast

Table Of Contents

Registration Information	2
Parts And Features	4
Before Using Your Appliance	7
Installation Of Your Appliance	7
Using Your Oven	7
Using Your Automatic Toaster	9
Care And Maintenance	9
Cleaning Your Toaster/Oven	9
Storing You Toaster/Oven	9
Troubleshooting Guide	10
Service For Your Appliance	10
Your Avanti Warranty	11
Wiring Diagram	12
Instrucciones En Español	13-16



To reduce the risk of fire, electrical shock, or injury when using your appliance, follow these basic precautions:

When using electrical appliances, basic safety precautions should always be followed including the following:

READ ALL INSTRUCTIONS, PRODUCT LABELS AND WARNINGS BEFORE USING THE TOASTER OVEN.

- ? Do not touch hot surfaces. Always use oven mitts when handling hot materials and allow metal parts to cool before cleaning. Allow the unit to cool thoroughly before putting in or taking off parts. Always use the oven handles when moving the unit.
- ? When the unit is not in use and before cleaning, unplug the toaster oven from the wall outlet. Make sure the oven is turned off before unplugging.
- ? To protect against risk of electrical shock, do not immerse the appliance in water or any other liquids.
- ? Close supervision is always necessary when this or any appliance is used near children. This appliance is not for use by children.
- ? Do not operate this or any appliance with a frayed or damaged cord or plug, after the appliance malfunctions, is dropped or has been damaged in any manner.
- ? Do not use attachments not recommended by the manufacturer; they may cause fire, electric shock or personal injury.
- ? Do not use outdoors or for commercial purposes.
- ? Do not use this appliance for other than its intended use.
- ? Do not let the cord dangle over the edge of a tabletop, countertop or to touch hot surfaces.
- ? Do not place the appliance near a hot gas, electric burner or in a heated oven.
- ? Extreme caution should be used when using containers constructed of other than metal or glass.
- ? A fire may occur if the toaster oven is covered or touching flammable materials, including curtains, draperies, walls, etc., when in operation. Do not store any items on top of the appliance when in operation.
- ? Do not store any materials, other than manufacturer's recommended accessories, in this unit when not in use.
- ? Do not place any flammable materials in oven, such as paper, cardboard, plastic or any materials that may catch fire or melt.
- ? Do not cover the oven with metal foil. This will cause overheating of the appliance.
- ? Oversized foods or metal utensils must not be inserted in the appliance as they may create a fire or risk of electrical shock.
- ? Do not clean with metal scouring pads. Pieces can break off the pad and touch electrical parts involving a risk of electrical shock.
- ? When broiling, use extreme caution when removing tray or disposing of hot grease.
- ? To turn this appliance off, return all controls to the "OFF" position.
- ? Cooked food can be very hot, especially pastry filling. Handle with care.

This Unit Is For Household Use Only

-Save these instructions-

Before Using Your Appliance

If you are using your toaster oven for the first time, please be sure to:

- ? Remove any stickers from the surface of the oven.
- ? Open oven door and remove all printed documents and paper from inside the toaster oven.
- ? Clean the racks, tray, and pan with hot water, a small amount of dishwashing liquid and a non-abrasive sponge or cleaning pad.
- ? Do not immerse the body of the unit in water.
- ? Dry the unit thoroughly before using.
- ? Check to be sure you have all of the following parts:
 - ? Drip Pan
 - ? Oven Wire Rack
 - ? Instruction Manual

Installation of Your Appliance

Select a location for the toaster oven. The location should be in an open area on a flat counter where the plug will reach an outlet.

- ? When positioning the oven, it should be set on a flat, steady surface.
- ? Do not block air vents. If they are blocked during operation, the oven may overheat and eventually cause oven failure.
- ? Keep the oven away from hot air, steam or splashing liquids when choosing a place to locate it, otherwise, the unit's operation may be adversely affected, causing it to break down.
- ? Direct sunlight may affect the acrylic coating and heat sources may increase electrical consumption.
- ? Plug the appliance into an exclusive properly installed wall outlet. Any questions concerning power should be directed toward a certified electrician or an authorized Avanti Products service center.
- ? Use of extension cords is not recommended.
- ? This appliance requires a standard 115/120 volt, 60Hz electrical outlet.
- ? Do not place anything on the top of the oven.
- ? The cord should be secured behind the appliance and not left exposed or dangling to prevent accidental injury.
- ? Keep the oven at least 5 inches away from both sidewalls and away from rear wall to ensure the proper ventilation.

Using Your Oven

Preheating The Oven

Turn the temperature control knob to the desired temperature.

Turn the function selector knob to desired time and allow 10 minutes for the oven to preheat.

To Use The Broil Function

Arrange food on broiler pan.

Place broiler pan on oven rack.

Close the door to the first notch, leaving approximately a 1-inch gap at the top. This will insure adequate airflow during broiling.

Turn the temperature control knob to the BROIL setting all the way to the end of the knob. Only the top heater element will operate.

Turn the timer knob to the desired time. The timer can be set to stay ON or for up to 15 minutes. The indicator lamp will be on. At the end of the cooking time a bell signal sounds and the oven turns off automatically.

Turn food over about halfway through the broiling time.

When broiling is completed, open door fully and remove food carefully.

To Use the Toast Function

Place the oven rack in the upper position.

No preheat period is required before toasting.

Place the bread to be toasted directly on the rack in the center of the oven, close the door.


Toast up to four slices of bread. When toasting only one or two slices of bread, center the bread in the oven.

Turn the temperature control knob clockwise to the TOAST setting.

Turn the TOAST/TIMER control clockwise to the desired toast color from "light" to "dark". Both the top and bottom elements will heat continuously when TOAST function is used.

When toasting is completed the bell will ring and the oven will automatically shut off, open door fully and remove food carefully.

Different types of bread require different settings. Lighter breads and waffles require a lighter setting. Darker breads, muffins, and English muffins require a darker setting.



To Use The Warm Function

The warm function is for warming and keeping food warm after heating.

The warming rack can be used to warm rolls, buns and croissants, which are too large to fit into the toasting slot.

Turn the function selector knob to the "WARM" setting shaded area on the knob. The heater elements will cycle ON and OFF to maintain temperature.

Turn the timer knob to the desired time. The timer can be set for up to 15 minutes. At the end of the cooking time a bell signal sounds and the oven turns off automatically.

Arrange food on the wire rack or in the baking pan.

When warming is completed, open door fully and remove food carefully.

To Use The Bake Function

Turn the temperature control knob to the desired temperature. Both the top and bottom heater elements will operate.

Turn the timer knob to the desired time. The timer can be set to stay ON or for up to 15 minutes. At the end of the cooking time a bell signal sounds and the oven turns off automatically.

Arrange food on the wire rack or in the baking pan.

When baking is completed, open door fully and remove food carefully.

When defrosting Do not preheat oven. Turn Temperature Control to 250°F. Allow 15-20 minutes per side for meats or fish to defrost. Always cook food promptly after thawing.

Using Your Automatic Toaster

The automatic toaster can fit all types of bread. Lighter and drier bread require a lower setting than whole meal or fresher bread, therefore we suggest you experiment to achieve the optimum result.

Place the bread to be toasted into the bread slot.

Set the toasting control to the desired setting and fully depress the lever, this will switch on the elements and set timer in operation.

The reset button is for use with the toaster function only.

As soon as the toasting cycle is complete, the toasted items will “pop up” ready for use.

After cycle has finished with the lever in its normal upper position, simply lift the lever to the top of its travel, this will allow easy removal of small items.

Toaster Control

This control may be rotated to vary the toasting time and therefore the degree of browning. To increase the browning, rotate the knob clockwise and vice versa although a wide range of settings (from 1 to 5) are available.

Numbers are positioned around the control for your guidance.

Care And Maintenance

Cleaning Your Toaster/Oven

Before cleaning your Toaster Oven, unplug it and allow it to cool. To clean, wipe with damp cloth. Do not Immerse in Water! Make sure to use only mild, soapy water. Abrasive cleaners, scrubbing brushes and chemical cleaners may damage the continuous clean coating on this unit. Empty crumb trays frequently to avoid accumulation of crumbs.

Storing You Toaster/Oven

Allow the appliance to cool completely before storing. If storing the toaster oven for long periods of time make certain that the toaster oven is clean and free of food particles. Store the toaster oven in a dry location such as on a table or countertop or in a cupboard shelf. Other than the recommended cleaning, no further user maintenance should be necessary.

PROBLEMS WITH YOUR APPLIANCE?

You can solve many common appliance problems easily, saving you the cost of a possible service call. Try the suggestions below to see if you can solve the problem before calling the servicer.

TROUBLESHOOTING GUIDE

PROBLEM	POSSIBLE CAUSE
Appliance does not operate.	Not plugged in. The circuit breaker tripped or a blown fuse.
Only one heating element is heating up.	Function setting selection determines which heating element will operate. When toasting, make sure the oven is not set to broil setting.
Heating elements do not stay ON	Heating elements will cycle ON and OFF to maintain proper heat.
Overcooked/undercooked Foods	Incorrect temperature or time setting. You may have to adjust the time and temperature to desired taste. Because your toaster oven is smaller than you regular oven, it will heat up faster and generally cook in shorter periods of time.
Burnt Smell	Food build-up inside oven, on heating elements or in crumb tray. Refer to "Cleaning Your Toaster Oven"

SERVICE FOR YOUR APPLIANCE

We are proud of our customer service organization and the network of professional service technicians that provide service on your Avanti appliances. With the purchase of your Avanti appliance, you can be confident that if you ever need additional information or assistance, the Avanti Products Customer Service team will be here for you. Just call us toll-free.

AVANTI PRODUCTS CUSTOMER SERVICES

Product Information 800-323-5029	Whatever your questions are about our products, help is available.
Part Orders 800-220-5570	You may order parts and accessories that will be delivered directly to your home by personal check, money order, Master Card, or Visa.
In-Home Repair Service 800-220-5570	An Avanti Products authorized service center will provide expert repair service, scheduled at a time that is convenient for you. Our trained servicers know your appliance inside and out.

YOUR AVANTI WARRANTY

LENGTH OF WARRANTY	WE WILL PAY FOR
FULL ONE YEAR WARRANTY FROM DATE OF PURCHASE ON ALL PARTS EXCEPT GLASS PARTS	REPLACEMENT PARTS AND REPAIR LABOR TO CORRECT DEFECTS IN MATERIALS OR WORKMANSHIP. SERVICE MUST BE PROVIDED BY AN AUTHORIZED SERVICE COMPANY.
FULL 30-DAY WARRANTY FROM DATE OF PURCHASE ON GLASS PARTS AND FINISH OF PORCELAIN ENAMEL, PAINTED OR BRIGHT METAL FINISHED PARTS	REPLACEMENT PARTS AND REPAIR LABOR TO CORRECT DEFECTS IN MATERIAL OR WORKMANSHIP. SERVICE MUST BE PROVIDED BY AN AUTHORIZED SERVICE COMPANY.

CARRY IN SERVICE ONLY

CUSTOMER WILL BE RESPONSIBLE FOR ALL TRANSPORTATION CHARGES TO AND FROM THE AUTHORIZED SERVICE COMPANY

AVANTI PRODUCTS SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES.

Some states Do not allow the exclusion or limitation of incidental or consequential damages, so this exclusion or limitation may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state.

This warranty is not valid outside the Continental United States.

WIRING DIAGRAM

INSTRUCCIONES EN ESPAÑOL

PRECAUCIONES IMPORTANTES

PARA REDUCIR EL RIESGO DE INCENDIO, DESCARGA ELECTRICA, O DAÑO CUANDO ESTE USANDO SU HORNO SIGA ESTAS INDICACIONES.

CUANDO USE APARATOS ELECTRICOS, SIEMPRE DEBEN TOMARSE ALGUNAS PRECAUCIONES BASICAS DE SEGURIDAD, INCLUYENDO LAS SIGUIENTES:

- ? **Lea todas las instrucciones, las etiquetas en el producto y las advertencias, antes de usar el horno tostador.**
- ? No toque las superficies calientes. Siempre use guantes cuando maneje materiales calientes y permita que las partes metálicas se enfríen antes de limpiar. Permita que la unidad se enfríe completamente antes de poner o quitar partes. Siempre use las asas del horno cuando mueva la unidad.
- ? Desconecte el horno tostador de la toma de corriente cuando la unidad no esté en uso y antes de limpiarla. Nota: Verifique que el horno tostador esté apagado antes de desconectar.
- ? Para protegerse contra una descarga eléctrica, no sumerja el aparato en agua o en otros líquidos.
- ? Supervisión continua es necesaria cuando éste o cualquier otro aparato sea usado cerca de niños. Este aparato no debe ser usado por niños.
- ? No opere éste ni ningún otro aparato con un cordón dañado o quemado o después de que el aparato ha funcionado inadecuadamente o ha sido dañado en cualquier forma.
- ? No utilice accesorios o aditamentos no recomendados por el fabricante, ya que pueden causar incendios, descargas eléctricas o lesiones personales.
- ? No se use en exteriores o con propósitos comerciales.
- ? No use este aparato más que para lo que ha sido diseñado.
- ? No permita que el cordón cuelgue sobre la orilla de la mesa o del mostrador o toque superficies calientes.
- ? No lo coloque sobre o cerca de quemadores de estufas de gas o eléctricas, tampoco dentro de un horno caliente.
- ? Tenga extremo cuidado cuando use contenedores de vidrio o metal.
- ? Puede ocurrir un incendio si el horno tostador está en operación y está en contacto o cubierto con materiales inflamables, incluyendo cortinas, tapicería, paredes, etc. No coloque ningún objeto sobre el aparato cuando esté en operación.
- ? Cuando esta unidad no esté en operación, no almacene ningún material que no sea un accesorio recomendado por el fabricante.
- ? No coloque dentro del horno ningún material inflamable como papel, cartón, plástico o cualquier material que se pueda incendiar o derretir.
- ? No cubra la bandeja para migajas o ninguna parte del horno con papel aluminio o metálico. Esto puede causar el sobrecalentamiento del aparato.
- ? Los alimentos grandes o utensilios metálicos no deben ser introducidos en el horno tostador ya que pueden causar incendios o descargas eléctricas.
- ? No limpie con esponjas o fibras metálicas. Se pueden desprender piezas de la esponja o fibra y tocar partes eléctricas creando el riesgo de descargas eléctricas.
- ? Cuando prepara alimentos, tenga cuidado extremo al remover la bandeja o al desechar la grasa caliente.
- ? Para apagar este aparato, regrese todos los controles a la posición "apagado/off".

-Esta Unidad Es Sólo Para Uso Doméstico-

Para reducir el riesgo de descarga eléctrica, este aparato tiene un enchufe polarizado (una clavija es más ancha que la otra). Este enchufe entra en un tomacorriente polarizado de una sola manera; si el enchufe no entra completamente en el tomacorriente, voltee el enchufe. Si todavía no entra, comuníquese con un electricista competente.

PREPARANDO SU HORNO TOSTADOR

Si usted está usando su horno tostador por primera vez, por favor asegúrese de:

Quitar todas las etiquetas de la superficie de su tostador.

Abra la puerta del tostador y saque los documentos impresos y papeles del interior del horno tostador.

Limpie la rejilla, charola y bandeja con agua caliente y una pequeña cantidad de detergente líquido para lavar platos, utilice una esponja suave y no abrasiva. No sumerja el horno tostador en el agua.

Seque completamente la unidad antes de utilizar.

Seleccione un lugar para colocar el horno tostador. El lugar debe ser una área abierta sobre un mostrador con superficie plana donde el enchufe tenga alcance a una toma de corriente.

Enchufe el cable en un tomacorriente de 120 voltios.

CALENTAMIENTO PREVIO DEL HORNO

Calentamiento Previo del Horno.

Coloque la rejilla en la posición deseada antes de calentar el horno tostador.

Gire la perilla de control de temperatura y colóquela en la temperatura deseada.

Gire la perilla selectora de función en la función deseada.

Coloque la perilla del reloj en el tiempo de cocción deseado y permita que transcurran de 9 a 11 minutos para que el horno se caliente previamente.

PARA USAR LA FUNCION DE CALENTAMIENTO

Nota: La función de calentamiento es para calentar o mantener los alimentos calientes después de calentarlos.

Seleccione la posición deseada de las rejilla.

Gire la perilla de control de temperatura y colóquela en la temperatura deseada.

Gire la perilla selectora de función en la posición de calentamiento o WARM. Los elementos calentadores se encenderán y apagarán alternadamente para mantener la temperatura.

Coloque la perilla de reloj en el tiempo de cocción deseado. El reloj puede seleccionar hasta 15 minutos.

Al final del ciclo de cocción, emitirá una señal auditiva y el horno se apagará automáticamente. Para fijar el reloj por menos de 15 minutos, gire el reloj antes de llegar al final y así activará el interruptor del reloj; puede fijarlo para cocinar alimentos que sólo requieren algunos minutos de cocción.

Coloque los alimentos sobre la rejilla metálica o dentro de la charola para hornear.

Cuando se haya completado el calentamiento, abra la puerta complementemente y saque los alimentos cuidadosamente.

PARA USAR LA FUNCION DE ASADO

Seleccione la posición deseada de la rejilla.

Cierra la puerta colocándola en la primera marca, dejando abierto aproximadamente un espacio de 1 pulgada en la parte superior. Esto asegurará que el aire fluya de manera adecuada durante el proceso de asado.

Gire la perilla de control de temperatura y colòquela en el nivel de temperatura más alto.

Gire la perilla selectora de función en la posición de asar o BROIL. Solamente el elemento calentador de la parte superior estará en funcionamiento.

Coloque la perilla del reloj en el tiempo de cocción deseado. El reloj puede seleccionarse para que esté OPERANDO hasta por 15 minutos. Al final del ciclo de cocción, emitirá una señal auditiva y el horno se apagará automáticamente. Para fijar el reloj por menos de 15 minutos, gire el reloj pasando la marca de los 15 minutos y así activará el interruptor del reloj; puede fijarlo para cocinar alimentos que sólo requieren algunos minutos de cocción.

Coloque la rejilla para asar dentro de la bandeja para hornear y así tendrá una bandeja para asar.

Coloque los alimentos en la bandeja para asar.

Coloque la bandeja para asar sobre la rejilla del horno.

Volteé los alimentos aproximadamente a la mitad del ciclo de cocción.

Cuando se haya completado la cocción, abra la puerta completamente y saque los alimentos cuidadosamente.

NOTA – Los elementos calentadores superiores se encenderán y apagarán alternadamente para mantener la temperatura.

PARA USAR LA FUNCION DE HORNEADO

Seleccione la posición deseada de la rejilla (consulte la sección de colocación de la rejilla).

Gire la perilla de control de temperatura al nivel deseado de temperatura.

Gire la perilla selectora de función en la posición de hornear o BAKE. Ambos elementos calentadores, el superior y el inferior estarán en funcionamiento.

Coloque la perilla del reloj en el tiempo de cocción deseado. El reloj puede seleccionarse para que esté OPERANDO hasta por 15 minutos. Al final del ciclo de cocción, emitirá una señal auditiva y el horno se apagará automáticamente. Para fijar el reloj por menos de 15 minutos, gire el reloj pasando la marca de los 15 minutos y así activará el interruptor del reloj; puede fijarlo para cocinar alimentos que sólo requieren algunos minutos de cocción.

Coloque los alimentos en la rejilla metálica o dentro de la bandeja para hornear.

Cuando se haya completado el horneado, abra la puerta completamente y saque los alimentos cuidadosamente. Cuando esté descongelando alimentos, no caliente el horno previamente. Gire el control de temperatura y colóquelo en 250°F.

Permita que cada lado de las carnes o pescados se descongele de 15 a 20 minutos. Siempre cocine los alimentos inmediatamente después de descongelar.

PARA USAR LA FUNCION DE TOSTAR

NOTA – No es necesario un período de calentamiento previo antes de tostar.

NOTA - Diferentes tipos de pan requieren de diferentes niveles de tostado. Los panes más ligeros y waffles requieren tostado más ligero. Los panes más oscuros, panqués y muffins o panecillos ingleses requieren un tostado más oscuro.

Seleccione la posición deseada de la rejilla.

Gire la perilla de control de temperatura al nivel de temperatura marcada "TOAST".

Gire la perilla selectora de función en la posición de tostar o TOAST. Ambos elementos calentadores superior y el inferior estarán en funcionamiento.

Coloque la perilla del reloj en el nivel de tostado deseado. Para fijar el reloj, gire el reloj hasta la marca de los 15 minutos y así activará el interruptor del reloj.

Coloque los alimentos en la rejilla metálica.

Cuando se haya completado el tostado, abra la puerta completamente y saque los alimentos cuidadosamente.

NOTA – Los elementos calentadores superiores se encenderán y apagarán alternadamente para mantener la temperatura.

LIMPIEZA DE SU HORNO TOSTADOR

Antes de limpiar su Horno Tostador, desconéctelo y permita que se enfríe. Limpie con un paño suave y húmedo. No lo sumerja en agua! Asegúrese de usar solamente jabón suave y agua. Los limpiadores abrasivos, cepillos y limpiadores químicos pueden dañar el acabado de esta unidad. Vacíe la bandeja para migas frecuentemente para evitar la acumulación de residuos.

ALMACENANDO SU HORNO TOSTADOR

Permita que el aparato se enfríe completamente antes de almacenar. Si va a almacenar el horno tostador por períodos prolongados, asegúrese de que el horno no contenga partículas o residuos de alimentos. Almacene el horno tostador en un lugar seco como encima de una mesa o mostrador, o sobre una repisa. Enrolle el cordón eléctrico alrededor del soporte para almacenar el cordón. No es necesario otro tipo de mantenimiento que no se sea la limpieza recomendada en este manual.

PROBLEMA	SOLUCION
Cocción excesiva o insuficiente de los alimentos.	Temperatura o tiempo incorrectos. ? Usted puede ajustar el reloj y la temperatura al gusto. ? Porque su horno tostador es más pequeño que su horno regular, entonces se calentará más rápidamente y generalmente cocinará en períodos de tiempo más cortos.
Olor a quemado.	Acumulación de residuos de alimentos en el interior del horno, en los elementos calentadores o en la rejilla para migas. ? Consulte la Sección “Limpieza de Su Horno Tostador”
El horno no inicia su operación Solamente un elemento calentador se calienta. El elemento calentador no se mantiene encendido.	La unidad está desconectada. ? Enchufe el horno tostador en una toma de corriente eléctrica 120 V . ? Coloque la perilla del reloj y de la temperatura en la posición deseada. Ambas deben de girarse para poner en funcionamiento el horno tostador. La selección de la función determina qué elemento calentador operará. ? Cuando tueste alimentos, asegúrese de que el horno no se encuentre en la función de asado. Los elementos calentadores se encenderán y se apagarán para mantener la temperatura adecuada. ? Asegúrese de que la función seleccionada es la función que desea utilizar.