



GS445LEM	SF196LEP
GS470LEM	SF368LEP
GS475LEM	SF369LEP
	SF380LEP

Electrical: A 120-volt, 60-Hz, AC-only, 15-amp, fused electrical circuit is required. A time-delay fuse or circuit breaker is also recommended. It is recommended that a separate circuit serving only this dryer be provided.

Technical drawing of a freestanding electric range. The drawing shows the front and side views of the appliance. Dimensions are indicated with arrows and text:

- Depth with handle: 27-1/8" (68.9 cm)
- Cooktop height: 36" (91.4 cm)
- Overall height: 46-7/8" (119.1 cm)
- Width: 29-7/8" (75.9 cm)
- Front panel height (excluding cooktop): 25" (63.5 cm)

Diagram illustrating the required clearances and dimensions for cooktop installation:

- 13" (33 cm) max. upper cabinet depth**
- 30" (76.2 cm) min. cabinet opening width**
- 30-1/8" (76.5 cm) opening width**
- 18" (45.7 cm) min. clearance upper side cabinet to countertop**
- 2" (5.1 cm) min. countertop space to side wall or other combustible material**
- 8" (20.3 cm)** (twice indicated for side clearances)
- 17" (43.2 cm)** (indicated for side clearance)
- 2" (5.1 cm)** (indicated for side clearance)
- 4-1/2" (11.4 cm)** (twice indicated for side clearances)
- For minimum clearance to top of cooktop, see NOTE.***
- If cabinet depth is greater than 24" (61 cm), oven frame must extend beyond cabinet fronts by 1/2" (13 mm) min.**
- * NOTE: 24" (61 cm) min. when bottom of wood or metal cabinet is protected by not less than 1/4" (6.4 mm) flame retardant millboard covered with not less than No. 28 MSG sheet steel, 0.015" (0.4 mm) stainless steel, 0.024" (0.6 mm) aluminum or 0.020" (0.5 mm) copper.**
- 30" (76.2 cm) min. clearance between the top of the cooking platform and the bottom of an unprotected wood or metal cabinet.**
- This shaded area recommended for installation of rigid gas pipe. Flexible gas pipe and electrical outlet are recommended in either shaded area.**